

[illegible]

© 2018 Gantner Instruments GmbH

Operating instructions, manuals and software are protected by copyright. Copying, duplicating, translating, conversion into any electronic medium or into machine readable form, completely or partially, is only permissible with the expressed consent of Gantner Instruments GmbH. An exception is the making of a copy of software for one's own use for backup purposes, where this is technically possible and recommended by us. Infringements will be pursued in law and will be subject to compensation claims.

All trademarks and brand names used in this document only indicate the respective product or the proprietor of the trademark or brand name. The naming of products which are not from Gantner Instruments GmbH is made exclusively for informative purposes. Gantner Instruments GmbH makes no claims on trademarks or brand names other than its own.

---

# Table of Contents

<b>1</b>	<b>Safety Information .....</b>	<b>7</b>
1.1	Intended use .....	7
1.2	Checking for damage in transit .....	7
1.3	Personnel .....	7
1.4	Siting locations .....	8
1.5	Modifications.....	8
1.6	Servicing and cleaning.....	8
1.7	Disposal.....	9
1.8	General hazards due to non-observance of the safety information.....	9
<b>2</b>	<b>Labels and warning information.....</b>	<b>11</b>
2.1	Warning information .....	11
2.2	Labels on the modules .....	11
2.3	Labels in this manual .....	11
<b>3</b>	<b>Introduction .....</b>	<b>13</b>
3.1	The documentation of the Q.brixx station.....	14
3.2	About this manual .....	14
3.3	System description.....	15
<b>4</b>	<b>Connectors and indicators .....</b>	<b>17</b>
4.1	Connector assignment for the Q.brixx station .....	17
4.2	Interfaces .....	18
4.2.1	Ethernet connection .....	18
4.2.2	USB connection .....	18
4.2.3	eSATA interface .....	19
4.2.4	DVI interface (external monitor) .....	19
4.3	LED flashing frequency.....	19
4.3.1	Flashing frequencies of the Q.brixx station.....	19
4.3.2	Module flashing frequency .....	20
<b>5</b>	<b>Q.brixx station connection .....</b>	<b>23</b>
5.1	Connect Q.brixx station to Ethernet network with server ...	23
5.2	Connect Q.brixx station to an Ethernet interface .....	23
5.3	Establishing a connection .....	24

5.4	Synchronization of several systems .....	25
5.4.1	Connection of a radio receiver for time signals.....	28
5.4.2	Connection of a GPS receiver .....	29
5.5	Installing the test.commander .....	30
5.6	Ethernet on the PC .....	31
5.6.1	Finding the IP address and subnet mask of the PC .....	31
5.6.2	Setting the IP address on the PC .....	33
5.6.3	Allowing access to network devices (firewall) .....	34
<b>6</b>	<b>Basic configuration of your system .....</b>	<b>37</b>
6.1	Q.brixx station basic settings.....	38
6.1.1	Settings .....	39
6.1.2	Module interface.....	40
6.1.3	Host interface .....	42
6.1.4	USB devices (GPS, Modbus, CAN).....	48
6.1.5	Sample rate and logger settings .....	50
6.2	System variable.....	50
6.3	Specifying digital inputs .....	51
6.3.1	Digital inputs .....	51
6.4	Virtual variable .....	54
6.4.1	Defining formulas and events .....	54
6.4.2	Defining CAN signals .....	56
6.4.3	Variable for computational results from a logger .....	59
6.4.4	Variable for the status of a logger .....	59
6.4.5	Defining Modbus RTU signals .....	62
6.5	Online tools .....	64
6.5.1	Read data buffer (with measurements) .....	64
6.5.2	Displaying measurements.....	65
6.5.3	Reading module information .....	65
6.5.4	Reading status information.....	66
6.6	Firmware update .....	67
6.6.1	Firmware update for Q.brixx station .....	67
6.6.2	Firmware update for modules .....	68
<b>7</b>	<b>Recording with the data logger .....</b>	<b>69</b>
7.1	Setting the sample rates (and data buffers) .....	69
7.2	Assign sample rates to the channels.....	72
7.3	Logger settings .....	73
7.3.1	Settings in the header section for Loggers 1 to 20 .....	74
7.3.2	Available variables .....	77
7.3.3	Details in the record settings section .....	78
7.3.4	Expert settings.....	83
7.3.5	Trigger and event settings.....	84

---

7.4	Examples .....	87
7.4.1	Continuous recording .....	87
7.4.2	Recording of a single event (repeated) .....	91
7.4.3	Angular synchronous measurement .....	95
<b>8</b>	<b>Access to data in the Q.brixx station .....</b>	<b>97</b>
8.1	Access through SMB/CIFS .....	97
8.2	Remote control by VNC .....	101
<b>9</b>	<b>International Sales and Service .....</b>	<b>105</b>



# 1

## Safety Information

Before starting installation, setting up, operation and before maintenance work is carried out, it is essential to read and follow the appropriate warning and safety information given in this manual.

Installation, setting up, operation and maintenance of the modules or devices must take place as intended, i.e. under the conditions of use laid down in this manual and in the technical data for the relevant module or device.

### 1.1

#### Intended use

The products in the Q.series range are intended for use in industrial and experimental test engineering and for monitoring assembly and production processes. Transducers (sensors) for the acquisition of physical quantities such as voltage, current, resistance, temperature, force, displacement, torque, mass, strain and pressure can be connected. The modules are used exclusively for these kinds of measurement and control applications. Any application which goes beyond this scope does not fall within the intended use of the modules.

To ensure safe operation the modules and devices must only be operated according to the details given in the manuals and technical data sheets. In addition, the required legal and safety regulations covering the respective application must be followed.

### 1.2

#### Checking for damage in transit

On receipt of the goods visually check that the packaging and the module or device together with the data medium are intact. Also check the shipment for completeness (accessory parts, documentation, auxiliary aids, etc.). If the packaging has been damaged in transit or if you suspect that the product is damaged or may malfunction, the product must not be put into operation. In this case contact your customer consultant or Gantner Instruments GmbH.

### 1.3

#### Personnel

The installation, operation and maintenance of the modules or devices must only be carried out by competent persons. Competent persons are those who through their professional education have sufficient knowledge in the required field and are familiar with the relevant national occupational protection regulations, accident prevention regulations, guidelines and accepted engi-

neering rules. They must be able to reliably assess the results of their work and must be familiar with the contents of this manual. Electrical connections must only be carried out by specialist personnel trained for the task.

In particular, pay attention to the following:

- the national installation and erection regulations (e.g. ÖVE, VDE, etc.)
- generally accepted engineering rules
- the details on transport, installation, operation, servicing, maintenance and disposal in this manual.
- the parameters, limits and the details about the operating and ambient conditions on the name-plates and in the data sheets.

## 1.4

### Siting locations

The devices in the Q.series range are protected to IP20 against water, dirt and small parts. If the ambient conditions require it, the modules can be fitted in water-protected or watertight housings.

Please note the admissible ambient temperatures specified in the technical data.

## 1.5

### Modifications

Making modifications to the modules or devices is not permitted. Dirt and shrouding covers may only be removed for service and maintenance purposes.

## 1.6

### Servicing and cleaning

The modules or devices do not need any servicing. Cleaning may only take place in the voltage-free state. Therefore follow the points below:

- Before cleaning, disconnect all connectors.
- Clean the housing with a soft, slightly moistened cloth. Never use any solvents, because these may attack the labels.
- When cleaning, make sure that no liquid enters into the device or goes onto the terminals.

Never attempt to repair nor to again operate devices which are defective, have developed a fault or are damaged. In this case it is essential to contact your customer consultant or Gantner Instruments GmbH.



## 1.7



### Disposal

Old devices which are no longer usable must be disposed of according to national and local regulations regarding environmental protection and raw-material recycling. Electronic components must not be disposed of with the household refuse. The packaging can be recycled and should therefore be passed into the recycling system. However, we recommend that the packaging is kept until the end of the warranty period so that you can pack faulty devices or modules properly.

## 1.8

### General hazards due to non-observance of the safety information

The modules or devices conform to the state of the art and are operationally safe. However residual risks may arise when they are used and operated improperly by untrained personnel.

Any person commissioned with the task of siting, operating, servicing or repairing a module or device in the Q.series must have read and understood the operating manual and in particular the information relating to safety.



## 2

# Labels and warning information

## 2.1

## Warning information


To prevent damage to property it is essential that you follow the warning information given in this operating manual.

**NOTICE**

Indicates a situation in which the consequence may be property damage if the information is not followed.

## 2.2

## Labels on the modules

Symbol: 

Meaning: This symbol is the CE marking. This shows that we guarantee that our product meets the requirements of the relevant EC directives.

## 2.3

## Labels in this manual

To simplify reading this manual we use the following labels and notation:

**! IMPORTANT**

Paragraphs with this symbol give important information about the product or about using the product.

**i Tip**

Contains application hints and other particularly useful information.

*italics*

signifies highlighted text

**interface**

signifies entries and entry fields in program user interfaces

**Options**

indicates menu items in the program user interfaces

>

signifies a sequence of menu items, e.g. in **Options > Settings**

➡

indicates special features or restrictions



# 3

## Introduction

Dear Customer,

Thank you for purchasing a product in the Q.series from Gantner Instruments GmbH. We are sure that you have obtained an excellent product which will enable you to make fast and reliable measurements with low measurement uncertainties.

If you find faults on the product or errors in the accompanying documentation or if you have suggestions for improvement, please contact your customer consultant or Gantner Instruments GmbH directly. We would be glad to receive your comments and ideas.

You will find further information in the section Technical Information in our Wiki at <https://dev.gantner-instruments.com/doku-wiki>. The user name is **support** and the password is **gins** (not all sections are open to the public).

### Austria

Gantner Instruments GmbH  
Montafonerstr. 4  
6780 Schruns/Austria  
Tel.: +43 (0) 5556 77463-0  
Fax: +43 (0) 5556 77463-300  
E-mail: [office@gantner-instruments.com](mailto:office@gantner-instruments.com)  
Web: [www.gantner-instruments.com](http://www.gantner-instruments.com)

### Germany

Gantner Instruments Test & Measurement GmbH  
Heidelberger Landstr. 74  
64297 Darmstadt  
Tel.: +49 (0) 6151 95136-0  
Fax: +49 (0) 6151 95136-26  
E-mail: [testing@gantner-instruments.com](mailto:testing@gantner-instruments.com)  
Web: [www.gantner-instruments.com](http://www.gantner-instruments.com)

## 3.1

### The documentation of the Q.brixx station

The documentation for the Q.brixx station consists of this manual. A further manual is obtainable for the modules to be connected to the Q.brixx station.

You will find this manual also as a PDF file on our home page [www.gantner-instruments.com](http://www.gantner-instruments.com) and on the Gantner CD enclosed with your Q.brixx station or which you can order free of charge from Gantner Instruments GmbH.

## 3.2

### About this manual

This manual describes the installation, operation and configuration of the Q.brixx station using the test.commander program. The programming of the Q.brixx station with the test.con program is described in a separate manual.

The manual is divided into several chapters:

- Safety information in Chapter 1, page 7ff.
- A description of the labels and symbols used on the Q.brixx station and in this documentation can be found in Chapter 2, page 11ff.
- An overview, showing a complete system (including modules) and which variants are available, can be found in the next section.
- The description of the terminal assignments on the inputs and outputs can be found in Chapter 4, *Connectors and indicators*, page 17ff.
- Chapter 5, *Q.brixx station connection* describes how you establish the connection to a PC, how you synchronize several Test Controllers and how you carry out a firmware update when required (page 23ff.).
- The basic configuration of your system, which settings you have to make via the test.commander program so that you can carry out measurements, is explained in Chapter 6, *Basic configuration of your system*, page 37ff.).
- The settings for recording data using one of the integrated data loggers as well as examples of logger configuration are included in Chapter 7, *Recording with the data logger*, page 69ff.
- Chapter 8, *Access to data in the Q.brixx station* describes the different possibilities how to access and transfer data stored in the Q.brixx station and how to control it remotely (page 97ff.).

### 3.3

## System description

The modules in the Q.series have been developed for industrial and experimental measurement and test engineering, in particular for multi-channel measurements of electrical, mechanical and thermal signals on engine and component test-rigs as well as for monitoring processes and long-term supervision.

Q.bloxx modules can be combined with the Q.brixx station to form one system as required. You can connect up to 16 modules to a Test Controller Q.brixx station and then address them from a PC or PLC via a single interface. The Q.brixx station can only be operated together with Q.brixx modules.

The Q.brixx station is obtainable in four variants:

Type	VGA display	PAC, graphically programmable with test.con, HMI Designer
Q.brixx station	connectable	-
Q.brixx station T	connectable	X

In this documentation the connection and configuration for both variants is described; only the description of the PAC functional features and working with test.con are not included in this manual.

### Application of the Q.brixx station

The Q.brixx station Test Controller is a programmable module with 1 Gbyte of RAM and an internal hard disk of which 1 Gbyte is available for data storage using logger functions. The Test Controller can be configured and programmed over wide ranges and in some versions it also has a graphical display. Optionally, you have EtherCAT slave, standard Ethernet with 1 Gbyte/s, USB interfaces, CAN bus and a web server available.

The Q.brixx station is twice as wide as the Q.brixx modules and must always be mounted to the left in the Q.brixx system. In one system you can operate up to 16 modules on the Q.brixx station. Here, 8 channels can be acquired at up to 100 kHz sample rate per channel. From firmware V1.1 onwards a 48 MBaud transfer rate and a resultant doubling of the speed are possible. A possible configuration with eight modules is shown in Fig. 3-1.




Fig. 3-1 Q.brixx system with Q.brixx station.

UART data throughput at 24MBaud Sample rate 10kHz Sample rate 100kHz	128 channels 16 channels
Ethernet data throughput (transmission rate with block transfer)	512 real variables (10kHz) 32 real variables (100kHz and 48MBaud)
EtherCAT data throughput (transmission rate)	Read 253 values and write 253 values at 10 kHz, cycle time $\geq 100\mu s$
Interfaces	Ethernet, EtherCAT, 1x CAN bus, SD card, 2x USB 2.0 with up to 4Mbyte/s, eSATA
Max. number of slaves	16



## 4

## Connectors and indicators

This chapter contains the description of the connectors (pin assignments) and the LED indicators.

## 4.1

## Connector assignment for the Q.brixx station

The Q.brixx station offers you eight digital inputs and four digital outputs, one CAN bus interface, two USB 2.0 interfaces and an eSATA interface for external storage media. The digital inputs are brought out via an 8-pole plug and the supply voltage via a 2-pole plug (Fig. 4-1).




Fig. 4-1 Terminal arrangement on the Q.brixx station.

### ! IMPORTANT

When accessing the Q.brixx station by FTP, USB1 is displayed as USB0 and USB2 as USB1.

We recommend that only screened CAN bus cable is used.

### Supply voltage

An unregulated direct voltage between 10 and 30 volts is needed for the power supply. The Q.brixx station itself needs approx. 12 W of supplied power; the power required for supplying the mod-

ules is not included. The power required is almost constant over the complete voltage range.

## Digital inputs

Pin	Digital input plug assignment
1 (red marking)	+5 V auxiliary voltage for digital inputs
2	DI1
3	DI2
4	DI3
5	DI4
6	DI5
7	DI6
8	Digital input 0V, GND

*Fig. 4-2 Terminal assignment of the socket for the digital inputs of the Q.brixx station Test Controller.*

You can freely assign the digital inputs using the test.commander (Section 6.3, page 51). The DI1 input must be used if you want to set up synchronization through IRIG-B and digital inputs. You can select the input level in the test.commander between TTL (switching level <1 V and >3.5 V) and PLC (switching level <7 V and > 8 V) (**Settings > General remarks > Digital input switching threshold**; refer to Section 6.1.1, page 39).

## 4.2

## Interfaces

### 4.2.1

### Ethernet connection

The Ethernet sockets use the standard pin assignment and you can directly insert standard Ethernet cable (RJ45). Cross cables are not needed and, if required, the switchover takes place automatically in the Q.station 101.

We recommend the use of cables to category Cat-5 or better.

### 4.2.2

### USB connection

The pin assignment of the USB sockets is as usual, so you can directly insert appropriate USB memory sticks. The memory sticks must be formatted in the ext3 or FAT32 format; other formats, e.g. NTFS, are not allowed.

**NOTICE**

The interface can be loaded with up to 100 mA. Use a separate power supply for devices with a higher current requirement (also start-up current), e.g. external hard disks.

---

The maximum transfer rate is approx. 4 Mbyte/s where this is supported by the connected memory device.

**4.2.3****eSATA interface**

You can connect all commercially available SATA hard disks or memories with SATA interface which are formatted in the ext3 or FAT32 format. Other formats, e.g. NTFS, are not allowed.

**4.2.4****DVI interface (external monitor)**

You can connect any commercially available monitor with a digital interface which can display a resolution of 1024 x 768. Monitors which use analog signals via the digital interface are not supported.

**4.3****LED flashing frequency****4.3.1****Flashing frequencies of the Q.brixx station****4.3.1.1****No error, everything OK**

The blue LED (RUN) lights permanently, the orange LED (ERR) is off.

**4.3.1.2****Storage to external memory running**

The blue LED flashes quickly. You can remove the storage medium, e.g. a USB stick, when the flashing stops.

**4.3.1.3****Error**

The blue LED lights permanently and the orange LED flashes (one flash with a pause in each case).

Read out the error status via the test.commander; refer to Section 6.5.4, *Reading status information* on page 66.

**4.3.1.4****Firmware error**

The orange LED lights permanently: The firmware could not be loaded.

The blue LED is off permanently: The FPGA cannot start the firmware.

Try a restart. If this does not help, please contact our [Support](#). In most cases the system can be reset by a service script which is

located in the subfolder *Additional* of the installation directory. Copy the script to a USB memory stick which you insert before switching the Q.brixx station on.

➡ Both the orange and the blue LEDs may light continuously. If this occurs for longer than about two minutes, the firmware update could fail. Try to carry out the update again or contact our [Support](#).


### 4.3.2

## Module flashing frequency

The modules have three LEDs: one blue LED on the upper edge and one red LED per connector strip. In normal operation the blue LED lights, but the red LEDs do not light. Depending on the error, the LED of the affected connector strip or the blue LED lights or all LEDs flash in a certain order. In the following illustrations a short dash corresponds to short flash and a long dash to a long flash.

#### 4.3.2.1

## SOS, configuration error



*Fig. 4-3 Flashing sequence with an incorrect module or when there are no settings in the base.*

Cause: The configuration saved in the base does not match that in the module.


There may be two reasons for this:

1. There is no configuration in the base yet.
2. The module type saved in the base configuration differs from the plugged-in module, therefore the configuration cannot be accepted.

Consequently, either change the module for the correct module type or reconfigure the module (Chapter 6, *Basic configuration of your system*, page 37). The (new) configuration is then automatically saved in the base.

#### 4.3.2.2

## Firmware download



*Fig. 4-4 Flashing sequence on downloading the module firmware.*

The LEDs flash while the firmware download into the module is taking place.

## 4.3.2.3


**Activating the firmware download**

Fig. 4-5 Flashing sequence on activating the firmware.

The LEDs flash while the firmware is being configured after a download. After the download the module must be restarted.

## 4.3.2.4


**Problems during data transmission**

Fig. 4-6 Flashing sequence for problems during the data transmission.

These flashing sequences indicate a problem with the communication. Check the following:

1. Is the interface link between the modules in order (are the bases plugged together or connected to the cables correctly)?
2. Is the interface link between the modules and the Test Controller in order?
3. Is wiring of the interface connections correct?

Then restart the system (by switching off, waiting one minute and then switching on again). If these measures do not remedy the error, then contact your customer consultant or Gantner Instruments GmbH directly.

## 4.3.2.5

**LED displays in normal operation**

For modules with analog inputs a red illuminated LED indicates that the measurement range has been exceeded on at least one input. You can suppress this indication in the module configuration.

For modules with digital inputs or outputs an orange illuminated LED indicates that an input or output is active.



# 5

## Q.brixx station connection

This chapter contains the description of how you connect the Q.brixx station to a PC.

Refer to the manual Q.bloxx for the connection of sensors and inputs/outputs to the Q.bloxx modules.

If you have connected a monitor to the Q.brixx station, you can enter the IP address via the display. To do this, connect a commercially available mouse to the USB port before you switch the Q.brixx station on (otherwise a restart is needed). Otherwise you must first establish communication once only with the Q.brixx station via the test.commander program. This can take place via a fixed IP address or the automatic address allocation (DHCP). If necessary, you can then allocate a fixed address for further operation to the Q.brixx station Test Controller; refer to Section 6.1.3.2, page 44.

- ➡ With a known address you can also establish a connection via the VNC Viewer; refer to Section 8.2, *Remote control by VNC*, page 101.

### 5.1

#### Connect Q.brixx station to Ethernet network with server

In the factory setting the Test Controller Q.brixx station uses DHCP (Dynamic Host Configuration Protocol), i.e. it receives a valid network address from a server which is present in the network. If you connect the PC to an Ethernet switch, an IP address is automatically allocated and you can establish the connection via test.commander.

---

**i Tip**

We recommend the use of industrial Ethernet switches. The Q.brixx station uses autonegotiation and operates, if available, with 1000Mbit/s and full duplex for the transmission.

---

### 5.2

#### Connect Q.brixx station to an Ethernet interface

If you are not connected to a network or if no server is located in the network, you have the following options:

1. You use a fixed address from the range 192.168.1.x for your PC. In principle with a network you can also establish a connection when the network uses a different address range. But it is better in these cases to establish a direct link initially and

then to allocate an address to the Q.brixx station from the address range of your network.

If the Test Controller does not receive an IP address from a server, then it adjusts to its static IP address after a few seconds. The factory setting of the static IP address is 192.168.1.28. Therefore, set your PC, for example, to 192.168.1.10.

2. You are using an external monitor and have connected a commercially available mouse via USB before switching on.

Click on the tile **Network** and in the following screen enter an IP address from the address range of your PC as the address for the Q.brixx station.

The IP address used (and whether DHCP is used or not) is shown in the display of an external monitor if one is used.




Fig. 5-1 Displaying the IP address.

#### **i** Tip

Refer also to Section 5.6, *Ethernet on the PC*, on page 31 for the display and setting of the PC IP address.

## 5.3

### Establishing a connection

A project is created by the test.commander in the course of establishing a connection. A project contains the hardware setup, the sensor and I/O settings present in the modules as well as the sensor signals used and computations, the so-called variables, which are to be output. You load this project later to be able to carry out settings.

#### Procedure

1. Make sure that the current version of the test.commander software is installed on your PC.  
You will find the current version in the download section of our home page. If necessary, install the current version; refer to Section 5.5 on page 30.
2. Start the software and select **Open initial operation assistant**.  
Another program window opens.



3. Enter a name for the project.
  4. Select the network adapter to which the Test Controller is connected.
  5. Specify which network type you are using.
    - a) **A DHCP server is available in the network used.** For a new Test Controller activate **DHCP is activated**.
    - b) **The controller will be connected to a network without DHCP server** or **The controller will be directly connected to the PC**.
  6. Make sure that the Ethernet interface of the Test Controller is connected and the power supply is only switched on after connection to the network or PC. Then click on **Continue**.
- ➡ If this is the first connection which you are establishing, you must obtain access to the network for the test.commander (requires administrator rights).
7. Wait until your Q.brixx station Test Controller is displayed. Mark the entry and click on **Continue**.

If the Test Controller is not shown, check the IP address in the display (if available). Otherwise check whether the server has allocated an address to the module. Also check whether the network cable is correctly inserted and, if necessary, whether the port on the switch is active. Then carry out a scan again.
  8. If you are not using a network with DHCP server, you obtain a dialog with the possibility of allocating a fixed IP address to the controller. Then enter an IP address from the range of your network or PC.
  9. Read the configuration out again, check the variables (names) and, if necessary, make corrections and open the assistant with a click on **Continue**.

Finally, a window is shown in which the Test Controller and all modules with the values of the measuring channels can be seen (provided they are configured and capable of measurement in the standard configuration).

Once you have seen the procedure, you can also carry out all the settings yourself for further projects, i.e. create a new (blank) project and then add your Controller Online, etc.

## 5.4

### Synchronization of several systems

The synchronization of the Q.brixx modules is ensured by the Test Controller Q.brixx station. You can also interconnect the Q.brixx station with other types of test controller, e.g. with Q.pac. With Q.gate the connection is possible optionally.

All synchronized modules operate synchronously and the maximum jitter is approx.  $\pm 0.5 \mu\text{s}$  over all modules. The synchroniza-

tion line transfers not just a clock signal, but also the date and time.

You have various methods of obtaining synchronization, even with several *systems*, i.e. several Test Controllers; (refer also to Fig. 5-2 on page 27):

1. Use the time signal in the Q.brixx station Test Controllers based on the IRIG standard (Inter Range Instrumentation Group) to synchronize all other Test Controllers to one master controller.

The master controller (the device which is *not* configured as a slave, refer to Section 6.1.1.3, *Synchronization*, page 40) uses its internal clock for the date/time stamp (gray path in Fig. 5-2). For this type of synchronization (inputs SyA and SyB) you must lay synchronization lines between the Test Controllers; the maximum length of all lines together is 400m. The master controller transfers the time stamp through an RS-485 link to the other Test Controllers. This method achieves the best time synchronization with the smallest jitter (approx.  $\pm 2\mu\text{s}$ ) between the individual modules, because the time information passes simultaneously to all Test Controllers.

2. You connect a radio receiver for time signals, e.g. for DCF77 which converts the received time signal to IRIG-B or AFNOR NF S87-500, to a Test Controller.

As master controller this then synchronizes all other Test Controllers using IRIG (orange colored path in Fig. 5-2) as with Variant 1. If it is not possible to connect the individual Test Controllers via synchronization lines or this is not desired, you can also connect a receiver to each Test Controller (Variant 2b).

3. You connect an NMEA-0183 compatible GPS receiver (Global Positioning System) to a Test Controller, which then, similar to Variant 1, synchronizes as master controller all other Test Controllers (from firmware V1.08).

With this method the time information of the GPS signal is evaluated instead of a pure time signal. In addition you can also process the position details of the GPS receiver in the system and assign the measurements (light blue path in Fig. 5-2). If it is not possible to connect the individual Test Controllers via synchronization lines or this is not desired, you can also connect a receiver to each Test Controller (also to a Q.gate Test Controller) (Variant 3b).

4. You define a PC as an SNTP time server which can distribute the NTP time stamp to all Q.brixx station, Q.gate or Q.pac Test Controllers (dark blue path in Fig. 5-2).
5. You use EtherCAT for the synchronization of the Test Controller (distributed clock).

**! IMPORTANT**

The maximum length of the synchronization cables on SyA and SyB is 400m.




Fig. 5-2 Possible types of time synchronization.

The absolute accuracy of the time information depends on the method used. If you do not want to use or cannot use any time synchronization lines, e.g. because the spacing of the systems is too large, you must expect greater deviations. In the variant 2b the deviations lie in the range from a few milliseconds up to about 100 milliseconds, but this depends on various factors, e.g. how often the time information is received. In the variant 3b the time accuracy of the GPS signal is decisive, which is only approx. 1 second absolute.

The fourth method uses, for example, the SNTP protocol (Simple Network Time Protocol) used in the Microsoft Windows operating system to transfer the date and time via Ethernet. However, the individual Test Controllers must always query the time server in order to be able to synchronize their times to the time server. The achievable accuracy is therefore not as good as for the first three methods. If required, you can also set up a (full) NTP time server

on a PC and synchronize it with a time server in the Internet. You will find further information about this at <http://www.mein-berg.de> (here you can also download a time server program) and at <http://www.pool.ntp.org>. The time accuracy is then only dependent on the change in the response times in your network. The fifth method receives the time signal from a EtherCAT master. Here, the time delay of the signal is fed back to the master (from firmware version 1.7.2) which then calculates a new time signal. The time resolution of the signal is 1 µs. The start date of this time calculation is 1.1.2000.

If you combine several synchronization methods, the best possible one is always used from those available:

1. Hardware synchronization (synchronization of the Q.series, EtherCAT, IRIG-B or AFNOR using a time signal, e.g. DCF77)
2. Time signal from GPS (NMEA-0183)
3. SNTP

The configuration of the synchronization in all cases occurs via the test.commander program. Apart from synchronization via SNTP (Section 6.1.3.5, page 47) you set the type of synchronization used via the menu **Settings > Synchronization**; refer to Section 6.1.1.3, page 40.

### 5.4.1

### Connection of a radio receiver for time signals

The Q.brixx station can process the following time signals:

- AFNOR NF S87-500
- IRIG B003
- IRIG B005

Depending on the output signal of your receiver you basically have the following methods:

1. The receiver, e.g. for DCF77, is connected to the digital IOs of the Q.brixx station Test Controller (plug-in terminal Digital Input, connections DI1 and GND; refer to Section 4.1, page 17f). The variant is suitable if the receiver outputs signals at a TTL level. This is the case, for example, with Hopf clocks (IRIG-B003 or IRIG-B005 depending on type) with TTL output (e.g. module 4465 with interface version 5).
2. The receiver is connected through the sync input (connections SyA and SyB; refer to Section 4.1, page 17). The variant is only possible when the receiver has an RS-485 interface, because the sync input uses this interface.

With **Settings > Synchronization**, specify which variant you are using; refer to Section 6.1.1.3, page 40.

## 5.4.2

**Connection of a GPS receiver**

NMEA-compatible or Garmin GPS receivers can be connected to the Q.brixx station Test Controller via the USB interface. If your device only has one RS-232 interface, you can use a commercially available RS-232-to-USB adapter.

Here, define the interface settings (for the connection refer also to Fig. 4-1 on page 17). If no new time information is received within the time period specified for the communication monitoring, the Q.brixx station uses the next available synchronization method.




Fig. 5-3 Settings for a GPS receiver from Garmin

**Evaluation of position data**

Use the variable *GetPositioningData* to evaluate the individual data items of your GPS receiver; refer to Fig. 5-4. You need one dedicated variable for each item of data supplied by your receiver. The various messages which contain the relevant value, e.g. GGA, are listed in the explanation of the command. You have to re-enter the port here, because several receivers may be connected.




Fig. 5-4 Output of the latitude (Parameter = 1) in a variable of the type ARITHMETIC\_EMPTY; the GPS receiver is connected to USB1 (Parameter = 100; refer also to Fig. 5-3).

## 5.5

### Installing the test.commander


- ➔ We recommend that you close all open programs before the installation. Administrator rights are needed for the installation.

Insert the Gantner CD into your CD drive. In the standard configuration Windows opens the CD automatically and a start window appears. If you have deactivated the Windows autostart function, find the file StartUp.exe in the main directory on the CD and give the corresponding symbol a double click to obtain the start window. Alternatively, you can also start the program Setup.exe in the folder test.commander to carry out the installation directly.

- ➔ The program ICP 100 is installed together with the program test.commander.

You will also find the relevant latest versions of the programs on our home page [www.gantner-instruments.com](http://www.gantner-instruments.com) via **Software > Download**.

**Procedure**

- Click on the symbol over **Load software**.
- Click on the symbol  next to the program which you want to install.  
The program Setup.exe is started.
- Allow the file to open so that the installation can start.  
The starting dialog of the setup program appears.
- Follow the instructions of the setup program to define the installation directory and the program group for the software.  
Setup.exe creates the directory you have specified, if necessary and then copies all files to it.

When the program test.commander is started for the first time, you specify the language for the program user interface (you can change your selection at any time via **Extras > Settings > Language**).

For the program a license number is needed which you have to enter to be able to save configurations. You will find the license numbers in the PDF file enclosed with the supplied items and on the separate printout with your license data.

Then enter your license data via **Help > Info and Licensing**. If you have licensed the program test.commander, then the program ICP 100 is also enabled and a further license is not required.


## 5.6

### Ethernet on the PC

The following sections describe various settings which you can carry out on the PC to enable a link to be formed. The images use menus and dialogs found in Windows 7; the names of the dialogs and fields in other versions of Windows are however similar and are usually also given.

#### 5.6.1

#### Finding the IP address and subnet mask of the PC

In Windows 7 or 8 open the **Network and Sharing Center**, e.g. using  at the bottom on the right in the taskbar. Click on the **LAN connection** (the name may be different) through which the Test Controller is connected to the PC (Fig. 5-5). In the following status dialog (similarly in Fig. 5-5) click on **Details**.

The current address is displayed in the next dialog under **IPv4 address**.

The subnet mask determines which addresses can be reached from the PC: Only addresses whose figures are identical in the places which contain a 255 in the subnet mask can be reached. The IP addresses of the PC and Test Controller should normally

be located in the same Ethernet segment (only the last group of figures in the IP address is different), otherwise the subnet mask must be 255.255.0.0 so that the last two groups of figures may be different.




Fig. 5-5 Viewing/changing the IP address of the PC.

### Example 1

Subnet mask 255.255.255.0, IP address 192.168.100.26

Only addresses can be reached which start with 192.168.100, i.e. the first three groups of figures must be identical and only the fourth may be different.

### Example 2

Subnet mask 255.255.0.0, IP address 192.168.100.26

All addresses can be reached which start with 192.168, i.e. the third group of figures may also be different between the PC and Test Controller.




## 5.6.2

## Setting the IP address on the PC

If you want to connect to a Test Controller, you must assign a (temporary) IP address to the PC.

- ➡ We recommend that a temporary IP address is set up on the PC, because then the network settings on your PC for the normal connections are not changed. If you have already set up this type of "alternative configuration" for another network, you must note the existing settings so that you can restore them after concluding the configuration of modules or the Test Controller.

In Windows 7 or 8 open the **Network and Sharing Center**, e.g. using  at the bottom on the right in the taskbar. Click on the **LAN connection** (the name may be different) through which the Test Controller is connected to the PC (refer to Fig. 5-5 on page 32). In the following status dialog click on **Properties** (requires administrator rights). Then mark **Internet Protocol Version 4** and click on **Properties** (refer also to Fig. 5-6).

Then proceed to the register card **Alternative Configuration** and specify an address for the PC, e.g. **192.168.100.5**, and a subnet mask, e.g. **255.255.255.0** (Fig. 5-7).




Fig. 5-6 LAN connection properties (Windows 7 and 8).




Fig. 5-7 Defining the IP address and subnet mask for an alternative (temporary) configuration.


### 5.6.3

#### Allowing access to network devices (firewall)

Generally, a firewall monitoring access of the PC to the network and vice versa is installed on the PC. Therefore, you must allow access to the Test Controller or the module, otherwise no connection can be established via Ethernet. On the first attempt to establish a connection you receive a message similar to that shown in Fig. 5-8. Click on **Unblock** to allow the connection.

#### ! IMPORTANT

You must possess administrator rights on the PC to be able to unblock the connection. If this is not the case, ask your administrator to do this for you. You must enable all programs for sharing which use an Ethernet connection to the modules or the Test Controllers.



*Fig. 5-8 Firewall message from Windows 7 when attempting to connect through Ethernet; here for the Setup Assistant.*



# 6

## Basic configuration of your system

You must first create a project and establish contact with the module before you can configure it. You will find a description of the working steps in Chapter 5, *Q.brixx station connection*, page 23.

The following chapter describes the most important settings to be able to measure with the Q.brixx station.

---

### IMPORTANT

If you would like to combine modules or Test Controllers from older applications and recently purchased ones, all components should use the latest relevant internal software, the so-called firmware. To ensure this, carry out a firmware update; refer to Section 6.6, page 67.

---



### Basic procedure

- Establish the connection (communication) between the PC and Test Controller; refer to Chapter 5, *Q.brixx station connection*, page 23.
- Start the configuration program.
- First, start with the basic configuration of the Test Controller and leave the definition of further settings, such as system variables or storage settings, to the end.
- Enter the sensors used and their sensitivities to obtain an indication in the measured physical quantity. Define computations, digital inputs/outputs, alarm monitoring, etc. These working steps are described in the manual for the Q.series modules.
- Specify which data are to be recorded and how; refer to Chapter 7, *Recording with the data logger*, page 69.
- Activate all settings in the modules and in the Test Controller.

---

### IMPORTANT

After changes to the configuration of modules or a Test Con-

troller  is displayed in the project tree. Select  or **File > Write project (update)** in the test.commander to update the settings in the project (and in the Test Controller). The project file is automatically saved.

---

### Tip

At many points in the software you can call the setting dialogs or settings via the context menu of an entry. You call the context menu with the right mouse key.

You process a complete variable in the configuration dialog in that you click on the variable in the left column (contains the variable number Vx) to mark it. Using the context menu, you can then cut, paste and copy the variable, overwrite it with a copied variable or delete it.

## 6.1

### Q.brixx station basic settings

In the Test Controller you specify, for example, the type and scope of the synchronization, set the (synchronous) output rate and baud rate of the modules to be used or define which bus diagnostic data or life signs are to be transmitted. In addition, you can check all the settings of host and module interfaces, allocate a location name, etc. The following sections deal with the most important settings; further settings are explained in separate chapters.

Mark the Test Controller to be set and select **Settings** from the context menu or double click on the Test Controller to start the configuration program.






Fig. 6-1 Configuration dialog for a Q.brixx station Test Controller (extract).

Then you can carry out all the module settings in the window of this dialog. A tree structure similar to that in Windows Explorer

shows the individual parameter groups. Open up the entries as required by a click on .

## 6.1.1

### Settings

Using this parameter group you define, for example, life signs or the location name.

#### 6.1.1.1

##### General remarks

##### Location

Here you allocate a name for the Test Controller, e.g. the location. The default setting is **Undef**.

##### PAC functionality

The PAC functionality offers the possibility of autonomously implementing (independent of the PC) any functions of many measurement quantities and I/Os, calculations, logical operations, time and transfer elements, etc. with the graphical software test.con.

Here, you activate or deactivate the general data access to Q.brixx station variables (read and write) of the test.con applications from real-time and user space. The default setting is **activated**.

##### Buffer pre-initialization

In the **Fast filling** default setting each measurement transferred with a bit error leads to an error: the measurement is set to -1 (default setting for **Filling pattern**) and the error counter is set. This generally causes the test-rig to stop. In the setting **Deactivated** the previous measurement is also used for the present measurement. If the next measurement is alright again, measurement continues as normal. The error is however counted, but no alarm is triggered. In the **Slow filling** setting the process is the same for two seconds as in the **Deactivated** setting, thereafter as in the **Fast filling** setting. In this way brief disturbances are ignored.

##### Filling pattern

Value which is used for a defective measurement (refer to Buffer pre-initialization).

##### Switching threshold of the digital inputs

Here, you select whether the TTL level (5 V) or the PLC level (24 V) is used for the digital inputs. With TTL the switching thresholds are <1 V and >3.5 V and the PLC levels are <7 V and >8 V. Refer also to Section 4.1, page 17.

##### System cycle frequency

The system cycle frequency provides the (internal) clock for the processing of virtual variables and test.con applications in the Q.brixx station. The cycle frequency can be set slower or equal to the highest sample rate. The maximum cycle frequency is 10 kHz; it determines the system load.

### 6.1.1.2

#### Life sign

Here you specify how the life-sign signal (Live signal) is to be produced. You can output a static signal which only changes its status when an error occurs or you can use a dynamic signal which changes its status between high and low with a certain frequency. You enter the frequency or the half-cycle time under I/O status change time in seconds. Choose the conditions for which an error is to be signaled.



#### IMPORTANT

The conditions change (note text) when you switch over from **Static** to **Dynamic**, because logical operations with AND or OR are carried out depending on the type of signal.

### 6.1.1.3

#### Synchronization

In the menu **Input synchronization protocol** you set both the type of synchronization used and also the inputs used for it.

If your device is operated as a slave, i.e. if you connect another Test Controller which has the time information available to SyA and SyB or you connect a radio receiver for time signals with an RS-485 output to these connections, specify **Q.sync via RS-485**.



#### IMPORTANT

The maximum length of the synchronization cables on SyA and SyB is 400 m.

Specifying **EtherCAT DC Time** (distributed clock) is only practicable when an EtherCAT master is present.

In the setting **None** the Test Controller operates with the internal time (as master for other connected Test Controllers).

If you want to synchronize via SNTP, you have to specify the time server using **Host interface > SNTP**; refer to Section 6.1.3.5, page 47.

### 6.1.2

#### Module interface

Using this parameter group you specify the speed of the data transmission on the individual interfaces (UARTs). Also, the baud rate for the CAN bus interface is set here.

#### 6.1.2.1

#### UART interfaces (RS-485 #1 to #4)

Select the required baud rate (transmission speed). The default setting is 24MBaud.






Fig. 6-2 Baud rate selection.

- ➔ A change in the baud rate is also carried out automatically on the modules connected to the interface.

#### Communication monitoring

With a value > 0 the module error LED is activated if there is a lack of communication after this period.

#### Response delay

This parameter is only needed when the modules are not directly connected to this interface, but instead connected to a modem, for example. Then enter the time here which is to be awaited additionally due to the slow connection.

#### 6.1.2.2

#### CAN bus interface

You can both read and send data over this interface. The maximum possible speed depends on the overall length of the cable which is connected to the relevant interface.

Cable length in meters	Maximum baud rate
1000	< 50 kBaud
100	< 500 kBaud
50	< 800 kBaud
25	< 1 MBaud

#### ! IMPORTANT

A change in the baud rate only affects the Q.brixx station; connected CAN devices must be set to the selected baud rate separately.

**Communication monitoring** With a value > 0 the module error LED is activated if there is a lack of communication after this period.

**Response delay** With this parameter you can specify an addition time-out period which is allowed to pass before communication monitoring signals an error.

### 6.1.2.3

#### Setting up a further CAN bus interface via USB

If required, you can use a further CAN bus interface by employing the PCAN-USB adapter from PEAK-System Technik GmbH (<http://www.peak-system.com>).

During the configuration of the Test Controller in the section **USB devices** specify **CAN** as the protocol and set the **CAN baud rate** to be used (Fig. 6-3). Refer to Section 6.4.2, page 56 for the definition of the data to be read in or to be output.




Fig. 6-3 Configuring the CAN interface via USB.

### 6.1.3

#### Host interface

This parameter group defines the settings for the communication over the interfaces EtherCAT, Modbus, Ethernet, FTP and Data-port and it enables you to implement access protection for the Q.brixx station.

Here you also have the possibility of specifying e-mail settings for messages from a data logger and of defining network drives which the Q.brixx station Test Controller can access for data storage. This means that a data logger can also save to a network drive and not just to a local drive.

#### 6.1.3.1

##### Field bus (EtherCAT)

The section contains the settings for the EtherCAT interface. Deactivate the interface if you do not need it.

**! IMPORTANT**

Using the context menu of the Test Controller and **Assign read/write accesses**, define which variables are to be available on the field bus. Activate the read access (**READ rights**) in the **Field bus** column for the relevant variable (Fig. 6-4).




Fig. 6-4 Enable read access for the field bus.

**Communication monitoring**

With a value > 0 and with a lack of communication after this period the error status becomes active; refer to Section 4.3.1, page 19.

**Frequency divider**

This value determines the transfer rate for the EtherCAT interface. The divider is required at high data rates to avoid overloading the interface. The value refers to the sample rate #1 and reduces, where applicable, the data rate on the EtherCAT interface. With a setting of 4 and a sample rate #1 of 4000 Hz the transfer rate is 1000 Hz (Fig. 6-5).




Fig. 6-5 Setting for the frequency divider.

**6.1.3.2****Ethernet**

Use this section to assign a fixed IP address to the Q.brixx station or to set it to DHCP again if you are using the version Q.station 101 or Q.station 101 T (without display).

- ➡ The stated static IP address is only effective when *no* DHCP server is being used.

The IP address used in the setting **Use DHCP server: Yes** can be found under **General remarks**; refer to Section 6.1.3.8, page 48.

**6.1.3.3****FTP****Server settings**

With the function **Server settings > Access names** you can implement access control (password protection).

**IMPORTANT**

You can work completely without any (**Access name: No**) or with *all three* passwords.

Note down the passwords and keep them in a safe place. If you have forgotten a password, note down the serial number of your Test Controller and contact us: [office@gantner-instruments.com](mailto:office@gantner-instruments.com). You then receive a release code which resets all three passwords.

**Client settings**

Here you define an FTP server with which the Q.brixx station can connect as client. You can then specify for a logger that the created files are sent directly to the FTP server.

**IMPORTANT**

You have to set up an FTP server appropriately on a PC. There are many programs which facilitate this, e.g. FileZilla.




Fig. 6-6 Details about the FTP server so that the Q.brixx station can access it as a client.

Check whether the settings for your FTP server at **Connecting timeout**, **Communication monitoring** or **Transmission interval** have to be changed. Then specify how many (maximum ten) FTP servers you would like to set up. The FTP servers can also only differ due to the directories. The directory specified at **Directory** is created as a subdirectory to the directory released in the FTP server.

#### Use passive mode

With a passive FTP the client sends a special command which causes the server to open a port and to send the port and IP address to the client. The client uses a port via 1023 and the port just transmitted by the server. This technique is necessary when the server itself is not capable of establishing a connection to the client, when the client is located behind a router or when a fire-wall screens the client from external access.

#### Type

Since the FTP server can be set up on any operating system, the client needs information about the form of the response to an interrogation of the directory. Unfortunately, this is not standardized and, depending on the operating system, the file information is transmitted in various formats. Using this, the client can request the size of a file. Therefore, with the **Unknown** format only a check is made of whether a file with the name of the transmitted file exists. A check cannot be made of whether the file has the right size, i.e. whether all the data has been transmitted.

#### Directory

With this option you can define a subdirectory on the FTP server. If you would like to save the data from different loggers in differ-

ent directories, simply create the same FTP server with different subdirectories, e.g. **/Data1** and **/Data2**.

### **i** Tip

Within the specified directory you can have the logger create further subdirectories by using *placeholders*. The placeholders possible are identical with those described in Section 7.3.1 for Logger name; refer to page 75.

### **!** IMPORTANT

A differentiation is made between upper and lower case in the directory path notation.

#### 6.1.3.4

#### Network drives

You can also use a network drive as the target memory for a logger, if you do not want to record on a storage medium on the Q.brixx station (e.g. on USB). You provide the required details via this dialog (Fig. 6-7).

#### Name

Here, enter the name which is to be used later in the logger for this target memory.

#### User name

Here, enter the user name for which the target memory, i.e. the directory, is released.

#### Password

Password for the user name.

#### Host name

IP address or name (requires a DNS server) of the PC on which the directory is located.




Fig. 6-7 Specifying network drives.

**Remote folder**

Here, enter the directory path, e.g. /Data/EngineTest. The path name corresponds to the directory path from the released folder. Example: You have released the subfolder DataFiles in the folder Testing on drive D:. The directory path is then **/DataFiles**, because (at least in the default setting) this is the name of the release on the relevant PC (host name). On release you can however also set a different name as the release name.

**6.1.3.5****SNTP**

Here, specify the IP address of the NTP server if you want to set up synchronization via NTP.  
Refer also to Section 5.4, page 25.

**6.1.3.6****E-mail**

For a logger to be able to send e-mails you must here define the possible selections for the fields **Address**, **Subject** and **Content**. In the dialog (Fig. 6-8) specify:

- To which server the mails are to be sent (**Sender server address**),
- whether and if yes, how the authentication is to occur,
- how many e-mail addresses and how much information (subject, content) you need.

You can specify up to ten different addresses, subject lines and content texts. You can state, for example, the location or test rig of the Test Controller in a **Signature**; the text is then always appended to the end of the mail.

For the configuration of the e-mail refer to Section 7.3.3.8, *Sending an e-mail*, page 82.




Fig. 6-8 E-mail settings.

## 6.1.3.7

**Dataport**

This section contains the settings for Modbus if this is being used via TCP/IP (Modbus/TCP).

## 6.1.3.8

**General remarks (own IP address)**

In the DHCP setting this shows the current IP address.


## 6.1.4

**USB devices (GPS, Modbus, CAN)**

In this section you can define special USB devices, e.g. a Garmin GPS receiver or generally an NMEA-0183-compatible GPS receiver (refer to Section 5.4, page 25), a Modbus interface or a PCAN-USB adapter (refer to Section 6.1.2.3, *Setting up a further CAN bus interface via USB*, page 42).

**Modbus interface**

You can also set up a Modbus connection via the USB-to-RS-485 converter ISK 103 from Gantner. The drivers for the converter are present in the Q.brixx station from firmware version 1.09, but you can also connect many commercially available converters.

Click on  or use **File > Read online status information from controller** to call up the status information of the Test Controller which shows whether the converter has been detected (Fig. 6-9).






Fig. 6-9 Status information with detected USB converter on USB1 (indicated as usb\_0).

Then define **Modbus** as the **Protocol** and specify the data for your bus system: Should the Q.brixx station operate as **Master** or **Slave**, which baud rate is to be used, etc. (Fig. 6-10). In the configuration as master you can, for example, receive data from an Ammonit Meteo-40 data logger or transfer Modbus data by radio via two Phoenix RAD-2400-IFS radio modules.




Fig. 6-10 Defining Modbus as the interface for the USB converter.

### Transfer format

Specify which parity is to be used: none (**n**), even (**e**) or odd (**o**). Eight data bits and one stop bit are always used so there are only the settings **8n1**, **8e1** (standard) and **8o1**.

**Communication monitoring**

With a value  $> 0$  and with a lack of communication after this period the error status becomes active; refer to Section 4.3.1, page 19.

**Response delay**

With this parameter you can specify an additional time-out period which is allowed to pass before communication monitoring signals an error.


The other settings can be carried out via the details for the virtual variables which are to receive data from this interface or send data to it; refer to Section 6.4.5, *Defining Modbus RTU signals*, page 62.

**6.1.5****Sample rate and logger settings**

With the Q.brixx station you can set up to four sample rates and data stores. On the data logger you define which data are saved, how often and where. The settings are written in a chapter of their own; refer to Chapter 7, *Recording with the data logger*, page 69.

**6.2****System variable**

Below the basic settings for the Q.brixx station there are also two entries for defining variables.

**IMPORTANT**

The variable **Timestamp** created in the default setting (DC system time, i.e. date and time since 1.1.2000) must not be deleted. You can however rename the variable. The time format has a resolution in  $\mu\text{s}$ .

In the System Variables section specify further time variables if you would like to use time formats other than the default system time. Context menu for system variables **Add new variable > ABSDATETIME**. After a double click on the variable and a further click on **Formula** you can then select other formats (Fig. 6-11).





Fig. 6-11 Dialog for specifying the time format.

In the System variables section (or in the Virtual variables section) you can also define time variables, e.g. if actions are to be carried out at a certain time of day or hourly: Context menu **Add new variable > ARITHMETIC\_EMPTY**. Then click on **Formula** to select a function.

## 6.3



### 6.3.1

## Specifying digital inputs

In this section you create the variables for your digital inputs. You can also combine several inputs to form a status field and use two inputs for an up/down counter or a rotated-angle signal with direction detection. PWM or frequency measurements are also possible.

### Digital inputs

In the context menu for Digital I/O select **New variable > DIGITAL\_INPUT**. You can also import existing variable definitions (**New variable > Open folder in Explorer**).




Fig. 6-12 Configuration dialog for a digital input.

### 6.3.1.1

#### Type of input

The setting determines how the input is used and which further settings you must carry out.

##### 1. Status

With this function it is only necessary to specify the connection terminal. You can leave all other settings on the default setting, because here only the high or low level is evaluated.

##### 2. Frequency

You can choose between a simple frequency measurement (**Frequency, standard**) and **Frequency, 2-wire**. The latter enables you to detect the direction of rotation through the sign of the frequency (rotational speed) using two digital inputs.

The setting cannot be currently configured interactively. If required, please contact our [Support](#).

##### 3. Counter

Here, you can choose between a simple counter (**Counter, standard**), a forwards/reverse counter with two signals offset by 90° (**Counter, quadrature 2-wire**), a forwards/reverse counter with a static direction signal for forwards/reverse (**Counter, up/down**) and a forwards/reverse counter with two 90° offset signals plus index signal (**Counter, quadrature 4-wire**), i.e. a reference signal at a zero position.

The setting cannot be currently configured interactively. If required, please contact our [Support](#).

#### 4. Pulse duration

**Pulse duration, period** measures the time between the low-to-high edges of a signal. **Pulse duration, active** measures the time at the high level, **Pulse duration, passive** measures the time at the low level. With **Pulse duration, PWM duty cycle** the ratio between the time period at high level to the time period at low level is evaluated.

If required, you can specify a conversion factor between the pulse duration or the duty cycle of the input signal and the displayed value using **Scaling type**. Set the **Data format**, e.g. to **SINT32** (signed integer, 32 bit), **Field length 8** and **Decimal** (places) **4** (the decimal point also counts as a place).


#### 5. Status field

With the Status field function you can combine several inputs to form a field. The inputs are evaluated as binary.


The setting cannot be currently configured interactively. If required, please contact our [Support](#).

The following block diagrams give you an overview of the possible circuits.


#### Measurement of status, time, frequency or PWM (Pulse-Width Modulation), 1 signal




#### Up/down counter or measurement of frequency and direction with static direction signal, 2 signals



### Measurement of frequency and direction or up/down counter with 2-channel frequency signal (90° phase delay)




### Measurement of frequency and direction or up/down counter with 4-channel frequency signal




## 6.4

### Virtual variable



With virtual variables you can implement calculations, evaluate trigger conditions, carry out assessments or define CAN bus or Modbus signals for input or output. The variables can be output like measurements or you can link them to other variables, measurements or digital I/Os. Virtual variables are also needed if you want to output computational results from a logger, e.g. by EtherCAT or Modbus/TCP. The maximum processing speed is 10 kHz.

#### ! IMPORTANT

After creating new variables select  or **File > Write project (update)** in the test.commander to transfer the new definition to the Test Controller. The project file is in this case automatically updated.

### 6.4.1

#### Defining formulas and events

In the context menu for virtual variables select **Add new variable > ARITHMETIC\_EMPTY**. After a double click on the variable you can either specify a formula for the computation, define

an event which is to be monitored (trigger) or specify the data format to be used (Fig. 6-13).




Fig. 6-13 Configuration dialog for a virtual variable.

Click on, for example, **Formula** to enter a computation (Fig. 6-14).

In the dialog you have available all variables already defined (tab **V1-10** and other tabs if more than ten variables have been defined). Click on one of the variables to insert it into the formula. Use the field **Functions and operators** to select a mathematical or logical function (select the function and click on **Select function** so that it is accepted into the formula field). Where required add brackets (simply enter them via the keyboard) in order to obtain the correct computational sequence. The syntax of the selected function is explained in the lower section of the window. If required, zoom on this section to be able to read the text easier.

Close the dialog with **OK**.




Fig. 6-14 Defining a computation (formula).

## 6.4.2

### Defining CAN signals

You have a number of ways of defining CAN signals:

1. Create input signals using the virtual variable **CAN\_INPUT**.
2. Create several input signals through the import of a Vector CANdb database.
3. Define output signals through the **CAN** symbol.
4. Define output signals through the virtual variable **CAN\_OUTPUT** (no longer recommended).

### 6.4.2.1

#### Defining single CAN signals

In the context menu for virtual variables select **Add new variable > CAN\_INPUT**. After a double click on the variable, you can change the name and enter the CAN parameters (Fig. 6-15).






Fig. 6-15 Example of a CAN signal.

#### 6.4.2.2

#### Importing CAN signals from CANdb

By importing signals from a CAN database in Vector CANdb format (file extension dbc) you can create several variables in one step. In the context menu for virtual variables select **Add new variable > Import CAN variables from DBC**. Select the file and in the following dialog (Fig. 6-16) mark the signals which you want to import. Marking messages reads all signals, but you can also mark individual signals.




Fig. 6-16 Selecting CAN signals or messages.

## 6.4.2.3

## Defining CAN outputs

Mark the Test Controller and click on the **CAN** symbol to call the dialog. In the dialog (Fig. 6-17) specify which signal is to be output on which CAN bus and how it is to be output.




Fig. 6-17 Defining output signals for the CAN bus.

The example in Fig. 6-17 illustrates several variants for transferring data:

1. The variable V6 (Load\_Cell) is output continuously (**Writing rule: Cyclical**) on **CAN 1** with the **CAN ID 305**; the **Cycle time** is 1000ms.
2. The variables V7 and V9 (Force left/right) are output in *one* message with the **CAN ID 306** when one of the values changes. Here, the variable V7 occupies the least significant 32 bits (**Start bit: 0**), the variable V9 the most significant bits (**Start bit: 32**).
3. The variables V8 and V10 (TensileForce left/right) are output via the CAN bus connected to USB 1 (refer to Section 6.1.2.3, *Setting up a further CAN bus interface via USB*, page 42) when one of the values changes. The **CAN ID** is in *both* cases **307**, i.e. the signal is **multiplexed**. The information of which signal is transferred is embedded in the **MUX value** (1 or 2). The value is transferred in the **Intel** format with the **MUX start bit 0** and the **MUX length 8** bits. You can mask out certain MUX values via the MUX mask (not used here).

**i** Tip

For the output signals defined here a Vector CANdb file is automatically produced in the project folder if you activate the option **Create CAN DBC file** using the menu **Extras > Settings and Project settings**.

## 6.4.3

**Variable for computational results from a logger**

In order to be able to output computations from a logger (refer to section *Create statistics or arithmetic channels*, page 77) or to use them in other computations, you have to “pack” them into a virtual variable.

In the context menu for virtual variables select **Add new variable > *LOGGER\_INTERNAL***.




Fig. 6-18 Configuration dialog for an internal logger variable

Select the logger which computes the variable and state the variable. All available (defined) variables are shown in the list (Fig. 6-18). Specify the data format, how the value is to be transferred and note which output is provided for this (with EtherCAT or Modbus/TCP you have to use at least two bytes).

## 6.4.4

**Variable for the status of a logger**

You also create a variable for a logger status in a similar way as for a variable for computations from a logger.

In the context menu for virtual variables select **Add new variable > *LOGGER\_INTERNAL***. Then specify **Logger status** as the **Variable type**.




Fig. 6-19 Configuration dialog for a logger status variable.

You then have numerous possibilities available in the **Status** field. For example, you can use the variable to check whether the logger is active (enabled), whether the start or stop trigger has occurred, how many files have been saved or also how much space is still present on the target drive (refer to Explanatory table of terms).

Status	Explanation	Parameter
Enabled	Indicates whether a data logger is activated	1 = Data logger saved 0 = Data logger not saved
Logging	Indicates whether the data logger is currently saved	1 = Storage process is active 0 = Storage does not take place
Start trigger	Indicates whether a start trigger is active	1 = Start trigger is active 0 = Start trigger is not active
Stop trigger	Indicates whether a stop trigger is currently active	1 = Stop trigger is active 0 = Stop trigger is not active
Saved files	States how many files the data logger has saved since the function was activated. This is not the number of files which the data logger has created since switch-on or shipment.	–
File progress	Filling level of the current file (0 - 100%). 100% signifies that the file is complete (setting of <b>Size of a single file</b> ).	–

Status	Explanation	Parameter
Trigger progress	<b>Storage length</b> of the current logger file in percent (0 - 100%)	-
Mails sent	Number of mails sent since the function was activated	-
FTP sent	Number of files sent by FTP since the function was activated	-
Target	Index of the target memory (from the list of target memories) on which storage is currently taking place. The index of individual target memories is shown with the status information of the test controller. In the mode <b>Automatic drive selection</b> you can find out to which memory writing is currently taking place.	Example: SD0 = Index 0 USB0 = Index 1 USB1 = Index 2
Target size	Total capacity of the memory in bytes. This is a fixed size which only changes when you connect another memory. Refer also to the following parameters.	-
Target remaining	This indicates how many bytes are still free on the memory medium to which writing is taking place.	-
Target occupied	This indicates how much space is already taken up on the current target memory (0 - 100%).	-
Data source overflow	Here, the value <b>0</b> should always be read. Otherwise ( $\geq 1$ ) the data are lost. The value states the number of overflows of the ring buffer.	-
Data source current size	This indicates how many bytes were in the ring buffer the last time the data logger wrote to it. The indication should always stay the same. If it becomes larger, then an overflow of the buffer memory is imminent.	-
Data source capacity	Maximum capacity of the ring buffer in bytes. This is a fixed size.	-

Status	Explanation	Parameter
Data source maximum size	This shows the size of the largest packet that has been fetched from the ring buffer by the data logger. The value remains valid as long as no buffer overflow occurs. The value is reset when the data logger is deactivated.	–
Post-processor <sup>1)</sup> overflow	Here, the value <b>0</b> should always be read. Otherwise ( $\geq 1$ ) the data are lost. The value states the number of overflows of the post-processor.	–
Post-processor <sup>1)</sup> current size	This indicates how many bytes were in the post-processor the last time the data logger wrote to it. The indication should always stay the same.	–
Post-processor <sup>1)</sup> capacity	Maximum capacity of the post-processor in bytes. This is a fixed size.	–
Post-processor <sup>1)</sup> maximum size	This shows the size of the largest packet that has been fetched from the post-processor by the data logger. The value remains valid as long as no buffer overflow occurs. The value is reset when the data logger is deactivated.	–

- <sup>1)</sup> Post-processor: When a data logger is not operating at the same speed as its data source, i.e. the ring buffer, or if data is being computed in the logger, the Q.brixx station produces a post-processor. The logger fetches its data from it. The post-processor and the ring buffer are therefore are memories where one directly follows the other.

### 6.4.5

### Defining Modbus RTU signals

In the context menu for virtual variables select **Add new variable > MODBUS\_RTU**.

#### Modbus interface

In Fig. 6-20 the USB-to-RS-485 converter ISK 103 is used to access the Modbus interface: **USB 1** (refer to Section 6.1.4, page 48).

#### Sensor address

Address of the receiving or transmitting bus device.




Fig. 6-20 Variables for Modbus signal.

**Modbus register type**

Depending on whether a value is to be read or written, you have to specify the appropriate Modbus register type in the dialog. For inputs usually the hold registers from 30,000 onwards are used and for outputs the registers from 40,000.

**Registers**

Here, you specify the register address to be used (from the range defined above).

**Modbus rules/  
writing rules**

Specify how values are to be read and written: **Cyclical**, only with a change of the value or on request (**via host**). With **Fast** the values are processed at the *system cycle frequency* (refer to page 39).

If you select **Cyclical**, you then have to state the **Cycle time**.

**Modbus data format**

Specify in which format the value is to be transferred on the Modbus. The FLOAT format requires four bytes and therefore two registers.

**Scaling**

Here, if required, you can scale the value transferred on the Modbus.

**Behavior on sensor error**

Here, you define the value to be displayed when the Modbus device no longer supplies any values.

**Data format  
(in the Q.brixx station)**

Here, you define in which format the value is provided in the Q.brixx station and whether it involves an input or output (data

direction). For example, you can convert a FLOAT value on the Modbus into DOUBLE, i.e. a 64-bit value (double precision). Note that the formats must have at least two bytes in order to be able to fully transfer the Modbus information.

### Reading/writing rights


Here or using the context menu of the Test Controller and **Assign read/write accesses**, define whether the variables are to be available for other interfaces. Then activate the access (**Read** or **Write**) for the relevant interface.

## 6.5

## Online tools

### 6.5.1

### Read data buffer (with measurements)

Click on  or use **File > Read online data buffer from controller** to be able to read out and view all values from the ring buffer.





Fig. 6-21 Display of the buffer content with test.viewer.

You can carry out further settings using the menu and symbols, e.g. display the channel list, show the spectra or transfer a live stream of data.



## 6.5.2

## Displaying measurements

Click on  or use **File > Read online values from controller** to be able to view the values of your variables. If you have defined appropriate variables, you can also set initial values in this dialog.





Fig. 6-22 Dialog for displaying the variable values.

In the dialog click on **Show online graphics** to display the values in a graph over time.

## 6.5.3

## Reading module information

Click on  or use **File > Read online module info from controller** to be able to display information such as the address or serial number of your system.





Fig. 6-23 Display of the module information.

## 6.5.4

## Reading status information

Click on  or use **File > Read online status info from controller** to display status information of your system.




Fig. 6-24 Display of the status information.

## Explanation of logger information

Act	States whether the logger is activated (1) or not (0).
Des	Target memory, e.g. sd0 (SD card).
Log	States whether the logger is currently recording (1) or not (0).
TOn	States whether the start trigger is active (1) or not (0).
TOff	States whether the stop trigger is active (1) or not (0).
TVal	Shows the current value of the trigger variable.
File	States the size of the current file in percent (0 - 100%).
Trig	States the progress of the current trigger process in percent (0 - 100%).
Stor	States how many files have been saved since starting the logger.
Mails	States how many mails have been sent since starting the logger.
FTP	States how many files have been sent since starting the logger.

## 6.6

### Firmware update

Recently purchased modules or Test Controllers always contain the latest firmware, i.e. the software in the modules or Test Controllers is the current version. However, if you want to combine these modules with older modules and/or Test Controllers, you must update all older modules or Test Controllers and it is essential to update your software to the latest version, because otherwise disturbances in operation due to a communication failure may occur.

The current firmware is in each case included in the latest installations of the programs ICP 100 or test.commander. Here, the program licenses apply to all versions of a program. If required, download the latest versions from our web site: [www.gantner-instruments.com](http://www.gantner-instruments.com). You will find the programs under **Software > Download**.

#### 6.6.1

#### Firmware update for Q.brixx station

Before a new installation is carried out, uninstall the existing version using the Windows Control Panel. Install the latest version of the test.commander so that you can also install the latest version of the firmware on your PC.

##### Procedure

1. In the program test.commander select **Utilities > Controller firmware update**.

The network in the segment of the PC address is searched and the Q.brixx station Test Controllers which are found are displayed in the window. If no Test Controller is found, you may have to enter the address manually or set the IP address of your PC to the segment used by the Test Controller; refer also to Chapter 5, *Q.brixx station connection*, page 23.

2. Mark the Test Controller to be updated and click on **OK**.  
The update tool is started and the Test Controllers present in the network are displayed again.
3. Mark the Test Controller to be updated and click on **Update**.  
The Windows file dialog is opened and shows you the latest firmware version available on your PC. (After the installation of the latest version the latest firmware is also installed. The version is found from the ID number of the Q.brixx station (module ID number)).
4. Mark the newest of the available firmware versions (if necessary, switch to the detailed view) and click on **Open**.  
The update process is started. Wait until the update has finished.
5. Click on **OK** and close the window of the update tool.

Wait until the Q.brixx station has finished the restart. The firmware update is now completed.

### 6.6.2

#### Firmware update for modules

Install as required the latest version of the test.commander so that you can also install the latest version of the firmware on your PC.

#### Procedure

1. In the program test.commander select **Utilities > Module firmware update**.
2. Make sure that the settings with regard to the interface used are correct: **Options > Communication settings**.
3. Search for the Test Controller or the modules: **Find modules**.
4. If the modules are connected via a Test Controller, in the next window mark the Test Controller to which the modules to be updated are connected and click on **OK**.

## 7

# Recording with the data logger

The Q.brixx station Test Controller enables you to save up to four sample rates in up to 20 data loggers. First, you specify how many sample rates you require (and associated data buffers). Then specify for the individual channels (UARTs) which sample rate it is to be used. In the third step you define the settings for the logger(s).

## ! IMPORTANT

The settings of the channels to be recorded are based on the channel names. When you retrospectively rename channels, the (old) channel names are no longer found and the relevant channels are deactivated.

The settings are made via the system view (allocation of the channels to the sample rates) and via the following context menus of the Test Controller:

- **Settings** for sample rates and data buffers,
- **Logger settings** for creating and setting the data loggers.

## ! IMPORTANT

The configuration files are not completely downwards compatible. Therefore, check all the settings (logging rate, recording modes, etc.) and the variables if you have carried out a firmware update of the Q.brixx station Test Controller and then loaded an old project.

## 7.1

## Setting the sample rates (and data buffers)

Call the dialog via the context menu **Settings** of the Test Controller (Fig. 7-1).

For each sample rate you also have to define a data buffer (ring buffer) which accepts the (original) values. Whether and how these values are processed later in the logger or via, for example, EtherCAT is not relevant here. You can, for example, use two data loggers and then “fill” one with the original sample rate and the other with a reduced data rate (= logging rate) (refer to Logging rate, page 78).




Fig. 7-1 Setting the sample rates.

### Number

Enter the required number of sample rates if you want to use more than one sample rate (up to 4 are possible).

- ➔ You should only use *one* sample rate per UART, especially with analog signals. *Two* sample rates which are to operate through *one* UART (one bus system) may otherwise lead to (small) inaccuracies in the time pattern of the measurements. If required, you can write single modules to a logger at a reduced data rate. However, the data buffer should be filled with the same sample rate for all modules of a UART. If in doubt, use the higher sample rate for all modules of a UART.

### Sample rate #1 to #4

Sample rate #1 (ring buffer 1) has a special role: It is the basic sample rate of the system. No other sample rate can be higher than sample rate #1. At the same time it provides the synchronization base for the other sample rates, i.e. the other sample rates are synchronized to this sample rate such that at time points where a measurement is taken at a lower sample rate, this occurs at a time point where a measurement also takes place at sample rate #1. This is not the case only in the **Synchronization source: external** operating mode.

#### **!** IMPORTANT

If you change sample rate #1, the system cycle frequency is also changed such that the ratio between the sample rate and the system cycle frequency remains the same. For example, if you have chosen a system cycle frequency of 1000Hz and you then reduce

sample rate #1 from 10,000Hz to 1000Hz, then the system cycle frequency is also reduced to 1/10, i.e. to 100Hz.

---

**Name**

You can leave the default name as it is or use the purpose of the sample rate in the name, e.g. **SlowSampleRate**.

**Synchronization source**

With the first sample rate you cannot specify a synchronization source, because this sample rate is the basic sample rate of the system.

In the default setting the other sample rates are internally synchronized to sample rate #1. With sample rates 2 to 4 you can however synchronize to an external signal (**Synchronization source: external**), e.g. to obtain a measurement with angular synchronization (refer also to Section 7.4.3, *Angular synchronous measurement*, page 95). In this case you have further entry fields available:

- **Digital input**

Specify on which digital input the synchronization signal is applied. Note that DI1 may be used for time synchronization.

- **Edge**

Specify whether the rising or falling edge is to be used.

- **Debounce**

If the signal is produced by a mechanical contact, you can suppress the effect of a bouncing contact with this setting: The level is only valid when – at a sampling frequency of 48 MHz – the number of samples (measurements) specified here exhibit the appropriate level (edge-dependent).

- **Minimum time between two syncs**

With this setting you can also suppress bouncing or brief disturbances after an edge: The next edge is only monitored when the time specified here has expired. Make sure that the specified time is shorter than the time between consecutive pulses at the highest rotational speed.

- **Reset mode for time stamp**

Here you can reset the cycle counter in particular for angular synchronous measurement. The Q.brixx station supports four different methods and further entry fields are provided depending on the method:

- Reset on reference pulse, i.e. when a (single) pulse occurs on the **Reset input for time stamp** (digital input), the counter is reset and the counting starts at one again with the next pulse.
- Reset on reference gap, i.e. pulses must also occur on the **Reset input for time stamp** simultaneously with the syn-

chronization pulses. If the pulse on the reset input is missing, the counter is reset.

- Reset on falling edge of the reference signal, i.e. when the level on the **Reset input for time stamp** goes low, the counter is reset.
- Reset on rising edge of the reference signal, i.e. when the level on the **Reset input for time stamp** goes high, the counter is reset.

Whether, when and which method you can use, depends on the angle sensor used. Usually a pulse on reaching the zero or starting position is output, i.e. depending on the length of the pulse, you can use the first or one of the two last methods.

### Sampling frequency

No sample rate may be higher than sample rate #1. The sampling frequency is the frequency with which the measurements are read into the Test Controller and it is independent of the logging rate of the logger.

- ➔ The updating of virtual and system variables is not determined by the sample rate, but rather by the cycle frequency of the system; refer to **System cycle frequency** in Section 6.1.1.1, page 39.

### Time stamp

With sample rates 2 to 4 you can also specify a different time source as the **System time DC** (distributed clock). The system time is always used in sample rate 1. This must not be changed. Specifying **Cycle counter** is practicable, for example, with external synchronization, in particular together with a reset signal; refer also to Synchronization source, page 71. With this you can, for example, implement a channel containing a measure for the angle and which is set to zero after each full revolution.

### Buffer size

The data buffer operates as a ring buffer, i.e. the oldest values are overwritten once the data buffer has been filled. Each data buffer can be read simultaneously from several points: Up to 10 connections are possible just over Ethernet alone.

Overall, for all (four) data buffers you have 200Mbyte available. This space can be divided as required. You can, for example, allocate half the space to one data buffer and divide the rest between the other three or use the whole space for one data buffer.

- ➔ The size must always be given in bytes, so therefore check the number of zeros. A figure given in seconds or similar is not possible.

## 7.2

### Assign sample rates to the channels

In the **Sample rate** column of the system view select the required sample rate for the relevant channels (Fig. 7-2). Later in



the logger settings only the channels are shown which are being acquired with the corresponding sample rate.

	Type	Connection	Range	Samplerate
Q.station 101 DT 192.168.100.1 (@192...				
System variables				
Digital I/O				
Virtual variables				
Q.bloxx A101 (2/2) TestStand3				
V5: Sensor1			-5100,0 ... 5104,3 N	Fast SampleRate
V6: U1			-10,000 ... 10,000 V	Fast SampleRate
Q.bloxx A101 (3/2) TestStand3				
V7: Sensor2			-5100,0 ... 5104,3 N	Slow SampleRate
V8: U2			-10,000 ... 10,000 V	Slow SampleRate


*Fig. 7-2 Selection of the sample rate, FastSampleRate and SlowSampleRate illustrated (you define the names when setting the sample rate).*

- ➡ You should only use *one* sample rate per UART for all modules, especially with analog signals. *Two* sample rates which are to operate through *one* UART (one bus system) may otherwise lead to (small) inaccuracies in the time pattern of the measurements. If required, you can write individual modules to a different logger at a reduced data rate (logging rate). However, the data *buffer* should be filled with the same sample rate for all modules of a UART. If in doubt, use the higher sample rate for all modules of a UART.



## 7.3

## Logger settings

The data loggers store the acquired values in one or more files. The storage speed (**Logging rate**) need not necessarily be the same as the sample rate. The files can be saved internally or externally and you can also set that the storage medium can be changed during the measurement. Refer also to Section 7.4, *Examples* page 87ff.

You call the logger settings via the context menu of the Test Controller or via .

## Create further loggers, delete loggers

At least one logger is always present and you can create others with a click on  above in the window. A maximum of 20 loggers is possible. A click on  deletes the relevant logger with all the settings (for safety you are queried again before deletion).




Fig. 7-3 Logger settings (example of a continuous logger).

### 7.3.1

## Settings in the header section for Loggers 1 to 20

### Data source

Here you select which sample rate (which data buffer) is to be used for this data logger. You choose how many values are actually stored via **Logging rate**; refer below.

#### ! IMPORTANT

The selection of any other data source resets all settings of the logger (right side).

### Logger type

Here, you choose between **Continuous**, **Triggered** and **Event-based**. After selecting **Triggered** or **Event-based** other options are displayed so that you can set the trigger conditions.




Fig. 7-4 Logger type **Triggered**.

You will find the special settings for triggered or event-based measurements in Section 7.3.5, page 84; the settings applicable to both logger types are explained in the following sections.

### Logger name

We recommend that a name is assigned which characterizes the purpose of the logger, e.g. **SlowMeasurement** or **ForceTrigger**. Using placeholders in the logger name, you can define a suitable folder structure for your files. Specifying **%YYYY-%mm-%dd/%HH/SlowMeasurement** creates the following folder structure if the *first* measurement of the *first* file was acquired at 8am on 25.01.2014:  
 \2014-01-25\08\SlowMeasurement...

### Available placeholders

Place-holder	Meaning	Example
%a	Day of the week, abbreviated	Thu
%A	Day of the week	Thursday
%b or %h	Month name, abbreviated	Aug

Place-holder	Meaning	Example
%B	Month name	August
%c	Date and time	Thu Aug 13:55:02 2014
%C	The first two places of the year figure	20
%d	Day with two figures	23
%D	Date in short form	02/23/14
%e	Day with two places (space character as prefix)	1
%F	Date (long form)	2014-02-23
%g	The last two places of the year figure, week-based	14
%G	Year figure, week-based	2014
%H	Hour in 24-hour format	13
%I	Hour in 12-hour format	01
%j	Day of the year	235
%m	Month with two figures	02
%M	Minute	55
%p	AM or PM	PM
%r	Time in 12-hour format	01:55:02 pm
%R	Time in 24-hour format	13:55
%S	Seconds	02
%T	Time to ISO 8601	1:55:02 PM
%u	Day of the week to ISO 8601 (Monday = 1)	4
%U	Calendar week with Sunday of the first week = 1	33
%V	Calendar week to ISO 8601	34
%w	Day of the week as number with Sunday = 0	4
%W	Calendar week with Monday of the first week = 1	34

Place-holder	Meaning	Example
%y	The last two figures of the year figure	14
%Y	Year figure	2014
%z	Time offset with respect to UTC time according to ISO 8601 in minutes	+100
%Z	Time-zone name or abbreviation	CDT
%%	Percent character	%

### Logger status

To use the logger with the following stated conditions you have to select **Activated** here (default setting). If the option is not active, the start/stop trigger is not evaluated. You can then activate or deactivate the logger status, for example, using the arithmetic function **InternalLoggerControl**. The logger status can also be changed via the **Expert settings**; refer to **Status**, Section 7.3.4, page 83.

### 7.3.2

#### Available variables

All channels which operate with the sample rate selected at **Data source** are displayed. Select those which are to be recorded by this logger.

#### Create statistics or arithmetic channels

If you do not want to record all values, but rather only statistical values such as minimum or maximum, etc., open the context menu for the variables (for the channel) and select the required value. **Add statistical values** generates all possible values (min/max/mean and the standard deviation) as subchannels. **Blank arithmetic** generates a computation channel (formula). You have the same functions available as with the virtual variables; refer also to Section 6.4, *Virtual variable*, page 54.

Double click on the new channel to define the settings (Fig. 7-5).




Fig. 7-5 Dialog for the functions Maximum and Reset.

If you have created a blank formula, click in the field to the right of **Formula** to call the input dialog. For the Max function illustrated in Fig. 7-5 you can either define that a variable or a digital input controls the reset (the variable **ResetMinMax** in the illustration) or that the value is reset after being stored at the logging rate (**In the storage interval: Yes**). In this case the logging rate should be significantly lower than the sample rate. If necessary, create a dedicated logger for such values; refer also to the next section.

**Example:** Maximum function, sample rate 3000Hz, logging rate 5 seconds. With this setting the maximum is formed over 15,000 measurements in each case and is then stored (1 value).

### 7.3.3

#### Details in the record settings section

You will find the special settings for triggered or event-based measurements in Section 7.3.5, page 84; the settings valid for both logger types are explained in the following.

#### 7.3.3.1

##### Logging rate

Here, you can define whether *all* values acquired with the sample rate specified under *Data source* (refer to Sample rate #1 to #4, page 70) are to be written into the data buffer or, for example, only every 10th value. A value greater than the sampling frequency is not permissible.

- ➔ The sample rate should be an integer multiple of the logging rate. For example, with a sample rate of 1000Hz select a logging rate of, for example, 100, 200, 250, 500 or 1000Hz, not however 300, 400 or 750Hz.

Select either **Hz** and enter the sampling frequency specified for the sample rate or enter a value lower than the sampling frequency. In order to store only every 10th value, enter **400Hz** for a logging rate (sampling frequency) of 4000Hz.

If you only require a few values, e.g. you only want to save one value every ten seconds, specify **Seconds** for **Logging rate** and **10** for **Value**.

### 7.3.3.2

#### Size of a single file

Depending on the logger type, you can specify the size of a file as the number of data records, in seconds, bytes or as a number of events. A data record corresponds to *one* measurement over *all* channels activated at **Available variables**. When the specified value is reached, a new file is started if the recording has not yet finished.

---

#### IMPORTANT

Up to 10,000 files can be saved on a storage medium.

---

- ➡ If you specify the file size as “rounded” time, the individual files are started at rounded times (rounding time feature). For example, if the first recording starts at 13:33:43 h and 150 seconds (2.5 minutes) are recorded, then writing to the first file only takes place up to 13:36:00h and then a new file is started, so that all other files start at “rounded” times (13:38:30h, 13:41:00h, etc.). This is also taken into account with a specification in minutes. However, if you specify, for example, 55 seconds, “rounding” does not take place to 60 seconds, i.e. “non-rounded” starting times occur.

The file name is formed from the logger name and the date and time of the *first* measurement. Using placeholders in the logger name, you can define a suitable folder structure for your files; refer to Logger name, page 75.

### 7.3.3.3

#### Event length

This setting is only available with the **Event-based** logger type. You define over how many data records, how long or how many bytes per event are to be logged. A data record corresponds to *one* measurement over *all* channels activated at **Available variables**.

### 7.3.3.4

#### Storage length

This setting is only available with the **Triggered** logger type. You specify the total time over which logging is to occur. The setting is independent of the size of the single file, i.e. it can be smaller or larger. If the value for the **Storage length** is greater than the size of the single file, then several files are written. Refer also to Section 7.4, *Examples*.

### 7.3.3.5

#### Type of storage

The type of storage determines how and in what sequence writing occurs to the target memories specified in the following. Now you have basically four options:

1. Storage on the newly connected data medium

Storage of the data occurs on the first available data medium with the file size specified under **Size of a single file**. If no further space is available here, the oldest two files are deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve).

When you connect a second data medium, the storage on the active data medium is terminated immediately and is written to the new data medium. You can remove the old data medium once the blue LED (RUN) no longer flashes rapidly (storage has then terminated). Otherwise the copied files may be damaged, refer also to Section 4.3.1.2, *Storage to external memory running*, page 19. This means that you can write alternately to two storage media, e.g. an external hard disk and a USB storage medium.

2. Automatic drive selection

Storage of the data occurs on the first available data medium in the list with the file size specified under **Size of a single file**. If no further space is available here, the next data medium in the list is used. If all available data media are full, the oldest two files in all data media are sought. They are then deleted and the relevant data medium is used further. The oldest files of this data medium are always deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve). With this option all the specified data media are used like a single large ring buffer.

To prevent the loss of data you have to read out the data *via the network* before overwriting.

3. Moving files

Storage of the data occurs on the specified data medium with the file size specified under **Size of a single file**. If no further space is available here, the oldest two files on this data medium are deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve).

When you connect another data medium, the data are moved onto this data medium, i.e. they are deleted on the original data medium. The transfer is indicated by rapid flashing of the blue LED (RUN). You can remove the data medium once the blue LED no longer flashes rapidly. Otherwise the copied files may be damaged, refer also to Section 4.3.1.2, *Storage to external memory running*, page 19.



#### 4. Copying files

Storage of the data occurs on the specified data medium with the file size specified under **Size of a single file**. If no further space is available here, the oldest two files on this data medium are deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve).

When you connect another data medium, the data are copied onto this data medium, i.e. they are retained on the original data medium and are not deleted as in the case of 3. With the selection of **... only new data** only the data which has not yet been copied are copied onto the newly connected data medium.

The copying process is indicated by rapid flashing of the blue LED (RUN). You can remove the data medium once the blue LED no longer flashes rapidly. Otherwise the copied files may be damaged, refer also to Section 4.3.1.2, *Storage to external memory running*, page 19.

#### Protected mode

The protected mode prevents unauthorized reading of your data. For this you require a specially prepared data medium which is coded to the Q.brixx station and the data medium used. In this matter contact the Technical Support (refer to Chapter 9, *International Sales and Service*, page 105), who will then produce an appropriate file for your storage medium using the details you provide. After selecting this option, the data are only transferred when a data medium coded in this way is connected. No data is transferred when another data medium is connected.

#### 7.3.3.6

#### Target memories

Storage of the data always takes place on the specified data medium or on the first available medium where there are several media. The maximum size of the **internal memory** (hd0) is 1 Gbyte.

- ➔ However, we recommend that the internal memory is only used with low data rates, because here the number of measurements which can be saved per second is relatively low.

Otherwise select a USB drive or a network drive.



#### IMPORTANT

Up to 10,000 files can be saved on a storage medium.

---

Whether and when writing to further media occurs depends on the settings for **Type of storage**.

---

**! IMPORTANT**

If only one medium is specified, this medium must not be removed as long as one of the loggers is active. Otherwise data may be lost. With storage on USB make sure that the correct USB interface is specified (refer to Fig. 4-1, page 17).

---

To facilitate the connection of several USB data media via a USB hub you can select various ports for the relevant USB interface.

If, as in Section 6.1.3.4, *Network drives*, page 46, you have defined one or several network drives, you can also define them as the target memory: select the **Name** specified there.

## 7.3.3.7

**Also send data to FTP server**

In order to be able to send data to an FTP server, you must first define the data for the FTP server(s); refer to *Client settings* in Section 6.1.3.3, page 44. The data are sent when the **Size of the single file** is reached.

Here, you select the FTP server.




Fig. 7-6 Send data to an FTP server

---

**i Tip**

Using the variable *SendFTPVirtualBufferFile*, you can also trigger the sending of a file to an FTP server. In this case you can leave the entry blank.


---

## 7.3.3.8

**Sending an e-mail**

In order to be able to send e-mails you must define the possible selections for the fields **Address**, **Subject** and **Content**; refer also to Section 6.1.3.6, page 47. The e-mail is sent when the **Size of a single file** is reached; the file is sent as an attachment.

### Make selection

You call the logger settings via the context menu of the Test Controller or via .

↓

☒ Send an additional e-mail

Address

Subject

Body

Fig. 7-7 Sending an e-mail.

Activate **Additionally send e-mail** and select one of the settings for the **Address**, **Subject** and **Content**.

## 7.3.4

### Expert settings

With the expert settings you can perform various general settings for any data logger. The default settings are suitable for most applications, so only change them if necessary.




Fig. 7-8 Expert settings.

### File storage mode

The **buffered** setting offers the fastest speed, but the operating system decides when writing is to occur. In the settings with **direct**, writing takes place directly without a buffer where possible, **sync** synchronizes the complete file system directly after every time writing to a file occurs (directory structure) and **fsync** only synchronizes the written file (updating where the file is located on the storage medium).

### Status

This basically corresponds to the setting of the logger status (Section 7.3.1, Logger status, page 77). In the **Single shot** mode the logger is only activated once at the trigger event. Depending on the setting for the file size, several files are also recorded as long as the trigger event is present. After recording, the logger is

deactivated in this mode and another trigger event is not awaited.

- ➡ You can also activate or deactivate the logger (again) in the **Single shot** mode via the arithmetic function **InternetLoggerControl**.

<b>Maximum files</b>	This defines how many files can be created as a maximum by this logger (0 to 4,294,967,295). The default setting is 10,000.
<b>Maximum bytes</b>	With this setting you can restrict the space in bytes available to this logger (0 to approx. $1.8 \cdot 10^{19}$ , longest 64-bit integer number). Specifying 0 (default setting) corresponds to no restriction.
<b>Maximum files in the directory</b>	This restricts the number of files which can be created in a directory. The default setting is 10,000.
<b>Automatic file deletion</b>	This deletes the oldest files once the space available on the storage medium has been occupied.

### 7.3.5

### Trigger and event settings



#### IMPORTANT

You must *measure* the channel used for the trigger condition or the event or the condition variable with the logger sample rate (same sample rate). The channel must therefore be listed and activated in the section **Available variables**.

The difference between **Event-based** and **Triggered** is that with **Triggered** both start and stop occur via a trigger event, whereas with **Event-based** only the start is initiated by an event (triggered) and a stop trigger does not exist: The quantity of data specified under **Event length** is always recorded.

<b>Start-trigger, event</b>	You can specify a channel or a computation as the <b>Condition</b> for the trigger. This can also be a channel, for which writing into the variable occurs, e.g. via EtherCAT from a PLC or from test.con. Click on the entry field to call the dialog for input. The field is displayed with a red font as long as no condition or an invalid one is specified. Specify whether the variable has to exceed (>), undercut (<), be greater than or equal to (>=), be less than or equal to (<=), be identical to (==) or only not the same as (!=) the specified value, so that the trigger or event is initiated.
-----------------------------	---



#### IMPORTANT

The start trigger must also be recorded.

**Stop-trigger**

Click on **Stop trigger** to change over between **Condition** and **None**. In the **None** setting storage is terminated when the **storage length** is reached.

You can specify a channel or a computation as the **Condition**. This can also be a channel, for which writing into the variable occurs, e.g. via EtherCAT from a PLC or from test.con. Click on the entry field to call the dialog for input. The field is displayed with a red font as long as no condition or an invalid one is specified. Specify whether the variable has to exceed (**>**), undercut (**<**), be greater than or equal to (**>=**), be less than or equal to (**<=**), be identical to (**=**) or only not the same as (**!=**) the specified value, so that the trigger is initiated.

---

**! IMPORTANT**

The stop trigger must also be recorded.

---

**Pre-trigger**

Using a pre-trigger you can define that a certain time is also recorded before the occurrence of the above defined start event. The figure can be given in seconds or as a number of data records. Click on **Pre-trigger** to switch the option on or off.

---

**! IMPORTANT**

The pre-trigger must fit into the buffer specified for the sample rate; refer to Buffer size, page 72.

---

When you specify a pre-trigger, values are continuously recorded in the internal memory. If the condition is fulfilled, the data present here is stored in the logger file.

**Post-trigger**

Here specify whether recording is to continue after the stop signal. The figure can be given in seconds or as a number of data records. Click on **Post-trigger** to switch the option on or off.

---

**! IMPORTANT**

With repeated measurements the pre-trigger condition is only evaluated again after the post-trigger has run.

---

**Event length**

This setting is only available with the **Event-based** logger type. You define over how many data records, how long or how many bytes per event are to be logged. A data record corresponds to *one* measurement over *all* channels activated at **Available variables**.

Refer also to Section 7.4, *Examples*.

**Storage length**

This setting is only available with the **Triggered** logger type.

You specify the total time over which logging is to occur. The setting is independent of the size of the single file, i.e. it can be smaller or larger. If the value for the **Storage length** is greater than the size of the single file, then several files are written. Refer also to Section 7.4, *Examples*.

## 7.4

## Examples

The following includes configuration examples for frequently occurring measurement tasks.

## 7.4.1

## Continuous recording

## 7.4.1.1

## Storage on a data medium, storage with or without data reduction

Continuous recording of all data is to take place. The values acquired with sample rate #1 (StandardMeasuringRate was chosen as the name) are to be written to a log file with a logging rate of 10Hz (ten values per second) over 300 seconds in each case. If the set sample rate #1 (StandardMeasuringRate) is higher than the logging rate, data reduction occurs. A logging rate higher than the sample rate is not permissible. Each file contains 3000 values per channel (300 seconds at 10Hz, Fig. 7-9).




Fig. 7-9 Example of a continuous recording.

The data are written to the SD card and must therefore be moved from time to time from there to a different medium, e.g. via the network. Otherwise, the two oldest files are deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve).

#### 7.4.1.2

##### **Storage on several data media, storage with or without data reduction**

Continuous recording of all data is to take place. The values acquired with sample rate #1 (StandardMeasuringRate was chosen as the name) are to be written to a log file with a logging rate of 10Hz (ten values per second) over 300 seconds in each case. If the set sample rate #1 (StandardMeasuringRate) is higher than the logging rate, data reduction occurs. A logging rate higher than the sample rate is not permissible. Each file contains 3000 values per channel (300 seconds at 10Hz, Fig. 7-10, page 89).

The data are first written to the SD card, then to the storage medium on USB1 and finally to the storage medium on USB2 (refer to Fig. 4-1, page 17). If all available data media are full, the oldest two files are sought. In the example they are located on the SD card and are then deleted. Thereafter, the SD card continues to be used; the oldest files of this data medium are always deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve). When all files have been overwritten once, the next target memory is used, here the storage medium on USB1.

With this option all the specified data media are used like a single large ring buffer. To prevent the loss of data you have to read out the data *via the network* before overwriting.






Fig. 7-10 Continuous recording on several data media.

#### 7.4.1.3

##### Storage on last connected data medium, storage with or without data reduction

Continuous recording of all data is to take place. The values acquired with sample rate #1 (StandardMeasuringRate was chosen as the name) are to be written to a log file with a logging rate of 10Hz (ten values per second) over 300 seconds in each case. If the set sample rate #1 (StandardMeasuringRate) is higher than the logging rate, data reduction occurs. A logging rate higher than the sample rate is not permissible. Each file contains 3000 values per channel.




Fig. 7-11 Example of a continuous recording (USB1 is the left USB interface; refer to Fig. 4-1, page 17).

The data are written to the first available storage medium (to the Fig. 7-11 SD card or USB storage medium). You must therefore promptly connect the second medium specified as the target memory. Otherwise, the two oldest files are deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve).

When you connect the second storage medium (**Target memory**), storage on the current medium is terminated, i.e. normally a file containing less than 300 seconds is produced. The blue LED (RUN) on the Q.brixx station flashes rapidly until the write process starts on the new medium. With larger storage media detection may take longer, so it is essential to wait until the LED starts to flash rapidly. When the blue LED flashes slowly again (this may

take longer than a minute), you can and must remove the first storage medium. Remove the data medium only when the flashing has stopped as otherwise the files may be damaged. The changeover from one storage medium to the next takes place when you connect a new medium.

## 7.4.2

### Recording of a single event (repeated)

#### 7.4.2.1

#### Control by start/stop condition and time limitation, storage on one data medium, transfer on connection of another one

Recording is to occur when the variable Start&Stop\_Cond. is greater than 0.5 (the variable is a digital input and contains the value 0 or 1). Overall, measurement should occur until the variable Start&Stop\_Cond. is again smaller than 0.5 or until 30 minutes have been recorded. Recording should take place at 10Hz.

With the settings from Fig. 7-12, page 92 the recording starts when the variable Start&Stop\_Cond. is greater than 0.5. As long as this is the case, a file is produced at 10Hz for each time for a maximum of 5 minutes (**Size of a single file**) and then a new file is started. When the variable Start&Stop\_Cond. is smaller than 0.5 or after 30 minutes at the latest (**Storage length** 1800 seconds), the recording is stopped, i.e. the file last produced is generally smaller than 300 seconds.

When a new start-trigger then occurs, i.e. when the variable Start&Stop\_Cond. is again greater than 0.5, the recording starts again.

The data are written to the SD card (**Target memory**). You must therefore promptly connect another storage medium, e.g. a USB data medium. Otherwise, the two oldest files are deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve). When you connect another storage medium, the transfer of the files begins. The blue LED (RUN) on the Q.brixx station flashes rapidly until the write process on the new medium has concluded. With larger storage media this process and also the detection of the storage medium may take longer, so it is essential to wait until the LED starts to flash rapidly. Once the blue LED flashes slowly again, you can remove the data medium (e.g. tap **Eject** on the display). Remove the data medium only when the flashing has stopped as otherwise the files may be damaged.




Fig. 7-12 Example of a triggered recording with time limitation.

#### 7.4.2.2

#### Start and stop a measurement with pre- and post-trigger, storage on one data medium, transfer on connection of another one

Recording is to occur when the variable Start&Stop\_Cond. is greater than 0.5 (the variable is a digital input and contains the value 0 or 1). However, the recording is to start before this event and the recording should also contain the measurements of 30 seconds before this event. Measurement should continue overall until the variable Start&Stop\_Cond. is again less than 0.5 plus a run-on period of one minute. The other recording parameters are as given in the previous example.




Fig. 7-13 Example of a triggered recording with start and stop trigger.

With the settings from Fig. 7-13, page 93 the values to be stored are initially written to an intermediate buffer which is 30 seconds in size, i.e. it contains 300 measurements per channel. When the variable `Start&Stop_Cond.` is greater than 0.5, this buffer is written to a file. (If the time for the pre-trigger is greater than the **Size of a single file**, then several files are written.) Thereafter, a file is produced with 10Hz in each case over 300 seconds and then a new file is started. When the variable `Start&Stop_Cond.` is less than 0.5, the recording continues for a further 60 seconds and, where necessary, a new file is also started.

At the end of the measurement storage occurs again in an intermediate buffer and when a new start trigger occurs, i.e. when the

variable Start&Stop\_Cond. is again greater than 0.5, the recording starts again.

---

**! IMPORTANT**

The start condition is only checked again when the post-trigger has terminated. If the start condition is fulfilled before the pre-trigger has expired, recording is started immediately.

---

The data are written to the SD card (**Target memory**). You must therefore promptly connect another storage medium, e.g. a USB data medium. Otherwise, the two oldest files are deleted and overwritten with new data (one file more is always deleted than written new in order to maintain a reserve). When you connect another storage medium, the files so far created on this medium are moved, i.e. they are deleted from the SD card after being written on the new storage medium. The blue LED (RUN) on the Q.brixx station flashes rapidly until the write process on the new medium has terminated. With larger storage media this process and also the detection of the storage medium may take longer, so it is essential to wait until the LED starts to flash rapidly. When the blue LED flashes slowly again (this may take longer than a minute), you can remove the (last connected) storage medium. Remove the data medium only when the flashing has stopped as otherwise the copied files may be damaged. Storage of the current measurements continues in the background during the transfer.

#### 7.4.2.3

##### **Event-based recording with pre-trigger and storage on a network drive**

Recording is to occur when the variable Start\_Cond. is greater than 0.5 (the variable is a digital input and contains the value 0 or 1). Overall, each event is to be recorded with 10 seconds pre-trigger and 30 seconds subsequent post-trigger (event length).

Recording should take place at 1000Hz.

Using the settings in Fig. 7-14 the pre-trigger buffer is initially filled. When the variable Start\_Cond. is greater than 0.5, this buffer is written to a file along with the following 30 seconds.

Recording takes place in each case at 1000Hz for 40 seconds. Thereafter the pre-trigger buffer is filled again and the event awaited. Once the specified 50 events have been recorded, the file is closed and a new one started.




Fig. 7-14 Event-based measurement.

The data are written to the network drive which you have specified in the basic settings using **Host interface > Network drive**. In this respect refer to Chapter 6, *Basic configuration of your system*, page 37, and Section 6.1.3.4, page 46.

### 7.4.3

#### Angular synchronous measurement

Carry out the basic setting for this measurement using the context menu **Settings** of the Test Controller (Fig. 7-15).




Fig. 7-15 Example of an angular synchronous measurement.

The signal from the rotary sensor (360 pulses/revolution) is fed into DI2. The sensor has a zero index signal (pulse-shaped) which is fed into DI3. The maximum rotational speed is below 20,000rpm, i.e. at least three milliseconds must pass before the next pulse can come.

The settings for the logger take place as in the other examples.



# 8

## Access to data in the Q.brixx station


You have several ways of reading out data from the Q.brixx station or of operating the Q.brixx station remotely.

1. From your PC you can access the Q.brixx station drives, e.g. the internal memory hd0, through a network and SMB/CIFS.
2. You can remotely control the Q.brixx station through VNC, e.g. using a VNC viewer.
3. You can transfer the data from the Q.brixx station to an FTP server; refer to FTP client in Section 6.1.3.3, page 44.

### 8.1

#### Access through SMB/CIFS

Enter the IP address of the Q.brixx station on your PC in the search box (Fig. 8-1) and press Return.



*Fig. 8-1 Entering the IP address.*

The Q.brixx station then appears with the IP address in the list of network drives or PCs (Fig. 8-2 on page 98).




Fig. 8-2 Q.brixx station as network drive.

You must enter the user name and password to be able to access the data. To do this, open the entry (the Data directory is shown) and double click on this directory (Fig. 8-3).




Fig. 8-3 Data directory on the Q.brixx station.

In the following dialog enter the user name (**data**) and password (**ginsdata**). Use **data** as password for older controllers with firm-ware 1.xx B0x.

- ➔ Note that Windows assumes that you want to log onto the current domain (if you are a member of a domain). In this case you must specify \data to bypass the prefixed domain (Fig. 8-4).




Fig. 8-4 Login dialog.

Then you are shown the internal memory as hd0 (Fig. 8-5).




Fig. 8-5 Internal memory of the Q.brixx station as network drive.

You can now access the drive just like any other network drive and copy or move files, etc.

Alternatively you can also select the menu **Extras -> Connect network drive** in any Explorer window (Fig. 8-6).




Fig. 8-6 Linking the Q.brixx station as Drive Q.

Then, you obtain, as in the first case, the login dialog (Fig. 8-4), in which you have to enter the user name **data** and password (**ginsdata**). Use **data** as password for older controllers with firmware 1.xx B0x. Then the internal memory is shown as hd0 on the drives of your PC.




Fig. 8-7 Drive Q contains the internal memory hd0.

Now you can also directly access (with both methods) the data directly with test.viewer and test.node. With test.node you can even check the logger settings.

## 8.2

### Remote control by VNC

The following section explains how you set up a remote control using TightVNC in order to be able to operate the (external) monitor of a Q.brixx station using the PC. This also works when no monitor is connected.

Download the program TightVNC (freeware under GNU General Public License Version 2) to your computer.

<http://www.tightvnc.com/download.php>.

- ➡ Note that the various installation programs depend on the operating system.

Then install the program (refer to Fig. 8-8 for an example).




Fig. 8-8 Installing TightVNC.

You only need the TightVNC Viewer to be able to remotely operate the Q.brixx station. For this use the installation type **Custom** (Fig. 8-9).




Fig. 8-9 Custom installation.

You then have the possibility of installing the TightVNC Viewer (Fig. 8-10).




Fig. 8-10 Installing the viewer.

Follow the further instructions of the installation program.  
 After installation start the program and enter the IP address of the Q.brixx station (Fig. 8-11).




Fig. 8-11 Logging onto the Q.brixx station.

In the next dialog enter the password **master** (Fig. 8-12).




Fig. 8-12 Entering the password.

Then the screen is shown in a window and you can operate the Q.brixx station by clicking on the fields (Fig. 8-13).




Fig. 8-13 Screen of the Q.brixx station in TightVNC

Of course, you can also use other VNC viewers. Enter the login data used above at the appropriate points.



## 9

## International Sales and Service

The current addresses of our sales partners can be found in the Internet on our web site. You can take up direct contact with Gantner Instruments GmbH at any time.

You will find further information in the section Technical Information in our Wiki at <https://dev.gantner-instruments.com/doku-wiki>. The user name is **support** and the password is **gins** (not all sections are open to the public).

### Austria

Gantner Instruments GmbH  
Montafonerstr. 4  
6780 Schruns/Austria  
Tel.: +43 (0) 5556 77463-0  
Fax: +43 (0) 5556 77463-300  
E-mail: [office@gantner-instruments.com](mailto:office@gantner-instruments.com)  
Web: [www.gantner-instruments.com](http://www.gantner-instruments.com)

### Germany

Gantner Instruments Test & Measurement GmbH  
Heidelberger Landstr. 74  
64297 Darmstadt  
Tel.: +49 (0) 6151 95136-0  
Fax: +49 (0) 6151 95136-26  
E-mail: [testing@gantner-instruments.com](mailto:testing@gantner-instruments.com)  
Web: [www.gantner-instruments.com](http://www.gantner-instruments.com)

© 2018 Gantner Instruments GmbH

Vers. No. 1.5  
Released: 15/10/2018  
Printed: 10/2018

#### Austria

Gantner Instruments GmbH  
Montafonerstr. 4  
6780 Schruns  
Tel.: +43 (0) 5556 77463-0  
Fax: +43 (0) 5556 77463-300  
E-Mail: [office@gantner-instruments.com](mailto:office@gantner-instruments.com)  
Web: [www.gantner-instruments.com](http://www.gantner-instruments.com)

#### Germany

Gantner Instruments Test & Measurement GmbH  
Heidelberger Landstr. 74  
64297 Darmstadt  
Tel.: +49 (0) 6151 95136-0  
Fax: +49 (0) 6151 95136-26  
E-Mail: [testing@gantner-instruments.com](mailto:testing@gantner-instruments.com)  
Web: [www.gantner-instruments.com](http://www.gantner-instruments.com)